




Ref #	Part Number	Qty	Description
1	121442X		SUB= 140119
2	121247X		SUB= 155925
3	105513X		SUB= 140551
5	121642X392		FENDER
6	106202X		REFLECTOR-TAIL YT
9	105511X		SUB= 140675
10	121067X		SPRING T
11	105531X		NUT-PUSH YT
12	105508X		BRKT FENDER T
13	6431J		PAD-SPACER T
14	121221X		SUB= 158990
15	106020X		SUB= 151346
16	3645J		BUSHING OUTLET T
17	8710J		FUEL TANK STEM GT
18	6999R		SUB= 123487X
19	5277J		SUB= 8543R
21	105523X		DASH PANEL T
24	105465X392		FOOTREST LH
25	101892X		DECAL T
26	108682X		NLA
27	108256X		PAD FOOTREST T
28	121306X		SUB= 127866
30	74180512		SCREW
31	121278X		CHASSIS
32	105464X392		FOOTREST RH
33	110828X		SUB= 133748
34	4171R		CLIP T
35	110436X		SUB= 9151R
37	121195X		SADDLE
38	1554J		SUB= 155108
39	109820X		DECAL YT
40	104805X		LOWER DASH
41	121312X		DASH
42	2029J		WELDNUT
43	121723X012		PLATE DASH
46	108372X392		SUB= 132638X424
49	122206X		DECAL - HOOD L.H.
50	106784X		SUB= 155013
51	104618X		SUB= 155013
52	108370X392		SUB= 150301X424
53	5479J		PLUG BUTTON T
54	110829X		SUB= 124130X
55	106965X		SUB= 140181
57	108371X392		SUB= 132639X424
58	122207X		DECAL - HOOD, R.H.
59	104613X		SUB= 147717
60	106395X		LENS LT
61	110855X		SUPPORT LH YTH
62	110854X		SUPPORT RH YTH
64	122100X		GRILL ASSY
65	105529X		SUB= 139888
66	73680500		SUB= 73690500
70	73680600		SUB= 73690600
71	17490608		SCREW LT
72	17490612		SCREW
74	72140606		BOLT
75	17431008		SUB= 98000165
76	74760616		BOLT

Ref #	Part Number	Qty	Description
77	121794X		COVER ACCESS
79	19091216		WASHER PM
81	73220400		SUB= 50675
82	74760532		BOLT
83	73510500		NUT
84	17211010		SCREW LT
85	104755X		""J"" FASTENER LT"
86	17490512		SCREW
88	7605J		BOLT T
89	73680400		SUB= 73690400
90	74191008		SCREW
91	10071000		LOCKWASHER
93	19131312		WASHER
96	74760612		SUB= 74780612
98	109808X		HOOD LATCH T
100	7206J		SPACER LT
101	19070818		WASHER
102	74981020		SCREW
104	19111116		WASHER
106	10090400		SUB= 10040400
109	2751R		CLIP T
116	121236X		SPACER
120	110853X		SUPPORT RH YTH
121	110852X		SUPPORT LH YTH
122	105419X392		STRAP GRILL
126	19131614		WASHER
127	17190412		SCREW
128	19091216		WASHER PM
131	11050400		LOCKWASHER
132	19111212		WASHER
134	121248X		BUSHING
135	73900400		NUT T
136	121246X		BRKT SWITCH
137	121249X		SPACER SPLIT
138	72170410		BOLT
139	121251		SUB= 121251X
140	121250		SUB= 121250X
141	74641008		SUB= 71031008
142	73951000		"NUT,KEPS"
143	122199X		SUB= 135062

### 12 H.P. HYDROSTATIC YARD TRACTOR

DRIVE




Ref #	Part Number	Qty	Description
1	120330X		MUFFLER LT
3	281707		ENGINE 12 H.P. TYPE 0201-01
4	2949R		SUB= 272293
5	101326L		DEFLECTOR.222573
7	10040400		LOCKWASHER
9	13200300		ELBOW
10	13280320		NIPPLE PIPE LT
11	91084		PLUG OIL DRAIN
12	121527X		SUB= 132764
14	108103X		SUB= 120418X
15	2751R		CLIP T
16	121187X		PLATE TRANS SUPT
17	121191X		SUB= 126649X
18	2703J		SUB= 123583X
19	73510600		NUT
20	121189X		U BOLT
21	121199X		SPACER SPLIT
22	121748X		WASHER
23	106108X		SUB= 106108X417
24	12000001		E-RING LT
25	104757X		HUB CAP
27	65139		VALVE STEM LT
28	59192		VALVE CAP
29	74610764		SUB= 71130768
30	19152405		WASHER LT
31	10040700		LOCKWASHER
32	108218X		SUB= 142600
33	109841X		SUB= 136905
35	74760644		BOLT
36	4859J		SUB= 123674X
37	4470J		SPACER T
38	19131312		WASHER
39	105730X		"KEEPER,BLT ENG LT"
40	121218X		KEEPER BELT ENGLH
41	109169X		SUB= 109172X
42	76020412		COTTER PIN
44	106888X		SPRING ROD LT
45	121200X		ROD BRAKE
46	8883R		PEDAL COVER T
47	106918X		ARM BRAKE LT
48	109037X		FOOT SHAFT PEDAL
49	1572H		SUB= 2882J
50	71673		PLUNGER CAP T
51	105844X		SUB= 125637X
52	105710X		"LINK, CLUTCH T"
53	73680600		SUB= 73690600
54	106499X		SUB= 123205X
55	12000039		KLIP RING
56	110812X		WASHER LT
57	105707X		"ASS T, BELLCRAN"
58	105709X		"SPRING, RETURN LT"
59	105724X		SUB= 123102X
60	74760624		SUB= 74930624
61	106298X		SUB= 139245
62	105706X		"LY, BEARING"
63	121749X		WASHER
64	2228M		SUB= 2228M1
71	76020412		COTTER PIN

Ref #	Part Number	Qty	Description
80	106268X		SUB= 122074X
80A	7152J		TUBE.18X9.5-8
82	108236X		BRACKET LT
84	110422X		SUB= 146682
91	4921H		SPRING.RETAINER
93	74760416		BOLT
94	71070510		SCREW LT
95	17450808		SCREW LT
96	120601X		DECAL.ENG.271967
97	67A223		SUB= 673A223
98	73350600		NUT
99	4497H		RETAINER M
100	10040500		LOCKWASHER

### 12 H.P. HYDROSTATIC YARD TRACTOR

#### ELECTRICAL



Ref #	Part Number	Qty	Description
1	123198X		SUB= 146525
2	19091016		WASHER
3	102476X		SUB= 150109
4	72240460		BOLT
5	121537X		SUB= 123899X
6	7603J		"TRAY T, BATTERY"
7	121533X		HARNESS
10	110859X		HARNESS T
11	7662J		SUB= 4152J
12	100541K		SUB= 7697J
13	7192J		WIRE TIE
14	104445X		SWITCH-INTER. GT
15	4206J		CABLE-BATTERY T
16	4406R		SUB= STD365402
18	109788X		SUB= 124211X
19	122147X		KEY
20	109081X		SUB= 146154
21	110712X		SWITCH LT
22	73680400		SUB= 73690400
26	719J		SUB= 154336
27	4207J		CABLE T
30	17021008		SCREW
30A	109748X		RELAY ASSY T
31	2751R		CLIP T
32	109596X		HOSE CLAMP T
33	10090400		SUB= 10040400
34	73350400		NUT
35	74780408		BOLT
36	73510400		NUT
37	74760412		BOLT LT
39	73220400		SUB= 50675
40	11050400		LOCKWASHER
43	10040400		LOCKWASHER
45	108824X		FUSE HYT
46	9433R		AMMETER T
47	6009J		SUB= 532131708
48	10101000		SUB= 10071000
49	73911000		NUT
50	19070818		WASHER
51	102501X		SUB= 141940
52	235R		CLIPT
55	4021J		SWITCH.PTO.T
56	4022J		HEX NUT T
57	109787X		SUB= 147626
58	121305X		SWITCH SEAT
61	121264X		"CAP,BATTERY "
	101539X		SHEET INSTR LT
	101572X		SHEET-INSTRUCTION (FRENCH)
	122308X		NLA
	122309X		OWNER'S MANUAL (FRENCH)




### 12 H.P. HYDROSTATIC YARD TRACTOR

### ENGINE BRIGGS & STRATTON -- MODEL NUMBER 281707, TYPE NUMBER 0201-01

#### STARTER - MOTOR

ALL ENGINE PARTS MUST BE PURCHASED THROUGH, AND WARRANTY  
SERVICE PERFORMED BY, YOUR LOCAL BRIGGS AND STRATTON DEALER




Ref #	Part Number	Qty	Description
1	94004		BOLT
2	94288		ROLL PIN
3	280104		GEAR, STARTER
4	490467		PINION SPRING KIT
5	398003		CLUTCH ASSEMBLY
6	490421		STARTER DRIVE GROUP
7	394857		DRIVE END CAP ASSY
8	394544		HOUSING ASSY
9	391160		ARMATURE ASSY
10	395538		BRUSH ASSEMBLY
11	395537		END CAP ASSY. COMMUTATOR
12	490420		MOTOR & DRIVE ASY

### 12 H.P. HYDROSTATIC YARD TRACTOR

ENGINE BRIGGS & STRATTON -- MODEL NUMBER 281707, TYPE NUMBER 0201-01

#### CARBURETOR

ALL ENGINE PARTS MUST BE PURCHASED THROUGH, AND WARRANTY SERVICE PERFORMED BY YOUR LOCAL BRIGGS AND STRATTON DEALER.




Ref #	Part Number	Qty	Description
1	270382		WASHER, FOAM
2	222010		VALVE, CHOKE
3	91920		SCREW, MACHINE, FILLISTER HEAD
4	26157		SPRING, THROTTLE ADJUSTMENT
5	93043		PIN, THROTTLE STOP
6	299740		NOZZLE CARBURETOR
7	292681		VALVE ASSEMBLY, CARBURETOR IDLE SCREW, SEMS
8	93499		SCREW
9	211712		STOP, THROTTLE
10	261116		SPRING, CHOKE RETURN
11	390684		SHAFT & LEVER, CHOKE
12	211960		VENTURI, CARBURETOR
13	221997		PLUG WELSH
14	490515		BODY ASSY CARBURETOR
15	270511		GASKET, FLOAT BOWL
16	299707		FLOAT, CARBURETOR
17	398970		SEAL, THROTTLE SHAFT
18	491006		SHAFT & LEVER, THROTTLE
19	222433		VALVE, THROTTLE
21	231323		SCREW
22	221995		BOWL, FLOAT
23	230896		PIN, FLOAT HINGE
24	394683		VALVE, FUEL INLET
25	93572		SCREW
26	222311		BRACKET, CARBURETOR
27	396568		VALVE, NEEDLE
28	222014		WASHER
29	491673		CARBURETOR ASSY
30	93357		SCREW, SEMS, CARBURETOR MOUNTING
31	270872		GASKET, CARBURETOR
32	280848		SPACER
33	394358		FILTER, FUEL
34	261610		LINK, CHOKE
35	67218		CONNECTOR, FUEL PIPE
36	93053		CLAMP, HOSE, GREEN
37	393815		HOSE (CUT TO SUIT)
38	93621		SCREW, SEMS
40	393295		STATOR, ALTERNATOR
41	93805		SCREW, SEMS
42	222562		SCREEN, FLUSH ROTATING
43	92284		NUT, FLYWHEEL
44	224061		WASHER, SPRING
45	222561		CUP, SCREEN MOUNTING
46	93535		SCREW, HEX HEAD
47	490420		MOTOR & DRIVE ASY
48	399676		GEAR, RING
49	492325		FLYWHEEL & RING GEAR ASSY MAGNETO
50	93984		SCREW, SEMS
51	490324		COVER, STARTER
52	94018		SCREW, AIR CLEANER
53	270853		GASKET, AIR CLEANER
54	490332		BODY
55	399806		CARTRIDGE - AIR CLEANER
56	223700		COVER
57	94246		
58	212706		
59	231532		NUT
60	94249		WASHER

Ref #	Part Number	Qty	Description
61	271962		ELEMENT - AIR CLEANER
62	94248		STUD
63	394698		CARBURETOR OVERHAUL KIT
64	393422		ALTERNATOR HARNESS ASSY
65	394890		REGULATOR, ALTERNATOR
66	93559		SCREW
67	93158		SCREW, SEMS
68	491922		PUMP, FUEL
69	393815		HOSE (CUT TO SUIT)
70	271853		WASHER, THROTTLE SHAFT, FOAM
71	492855		REPAIR KIT - FUEL PUMP
72	244130		BRACKET, IMPULSE PUMP MTG.

**12 H.P. HYDROSTATIC YARD TRACTOR**  
**ENGINE BRIGGS & STRATTON -- MODEL NUMBER 281707, TYPE NUMBER 0201-01**  
**CYLINDER BLOCK GROUP**


ALL ENGINE PARTS MUST BE PURCHASED THROUGH, AND WARRANTY SERVICE PERFORMED BY YOUR LOCAL BRIGGS AND STRATTON DEALER






Ref #	Part Number	Qty	Description
1	19203		PULLER, FLYWHEEL
2	93705		SUB= 69485
3	223752		GUARD, FLYWHEEL
4	490853		HOUSING, BLOWER
5	93158		SCREW, SEMS
6	398811		ARMATURE, MAGNETO
7	221798		TERMINAL, IGNITION CABLE
8	93381		SCREW, SEM, ARMATURE MOUNTING
9	398808		WIRE, GROUND
10	231531		SPACER, CLUTCH
11	223726		RETAINER FAN
12	93535		SCREW, HEX HEAD
13	280687		FAN, FLYWHEEL
14	398525		INSULATOR ASSEMBLY
15	92791		WASHERLOCK
16	93722		TERMINAL, SPADE
17	90576		NUT, HEX
18	26157		SPRING, THROTTLE ADJUSTMENT
19	90200		SCREW
20	93572		SCREW
21	260871		SPRING, GOVERNOR
22	491594		PLATE, GOVERNOR CONTROL
23	221535		CLAMP
24	93496		SCREW, SEMS
26	262348		LINK, GOVERNOR
27	260584		SPRING, GOVERNOR LINK
28	93307		RETAINER, E-RING
29	93306		COTTER, HAIR PIN
30	231058		CRANK, GOVERNOR
31	222450		WASHER, GOVERNOR LEVER
32	92613		BOLT, GOVERNOR LEVER
33	231082		NUT, HEX
34	490927		LEVER ASSY, GOVERNOR
35	212359		LINK, COUNTERWEIGHT
36	93875		SCREW, COUTENWEIGHT
37	298909		PIN ASSY, PISTON, STD
38	399891		COUNTERWEIGHT ASSY
39	490815		GOVERNOR GEAR
40	490525		GASKET SET
41	490450		CYLINDER ASSEMBLY
42	399265		P/N CONFLICT - CHECK WITH SUPPLIER
43	391086		SEAL, OIL
44	223715		SHIELD
45	93163		SCREW
46	491490		COVER, CYLINDER HEAD
47	271866		GASKET, CYLINDER HEAD
48	261463		SEAT, INTAKE VALVE, STANDARD
49	210940		SEAT]
50	261961		GUIDE, EXHAUST VALVE
51	491986		BUSHING, GOVERNOR CRANK
52	27803		GASKET, VALVE COVER
53	280100		TUBE, BREATHER
54	93394		SCREW, SEMS, BREATHER, MOUNTING
55	394217		BREATHER, ASSY
56	222698		KEY, FLYWHEEL
57	490466		CRANKSHAFT
58	262135		GEAR, TIMING
59	262247		VALVE, INTAKE

Ref #	Part Number	Qty	Description
60	65906		SPRING, INTAKE VALVE
61	221596		RETAINER, INTAKE VALVE
62	262246		VALVE, EXHAUST
63	26828		SPRING, EXHAUST VALVE
64	93630		RETAINER, EXHAUST VALVE ROTOCOIL(2)
65	292260		RETAINER, EXHAUST VALVE
66	262248		TAPPET-VALVE
67	212897		GEAR, CAM
68	94305		SCREW, SEMS, BASE MOUNTING
69	91084		PLUG OIL DRAIN
70	291675		SEAL, OIL
71	271916		GASKET, CRANKCASE COVER 1/64"
71	271996		GASKET, CRANKCASE COVER .009"
71	271997		GASKET, CRANKCASE COVER .005"
72	490452		BASE
73	490327		CAP AND DIPSTICK, OIL FILLER
74	270920		SEAL, OIL FILLER CAP
75	93804		SCREW
76	223721		CLAMP, OIL FILLER TUBE
77	280741		TUBE, OIL FILLER
78	68838		SEAL, FILLER TUBE
79	490474		FILL GROUP, OIL
80	394665		RING SET
80	391781		RING SET, PISTON .010" OVERSIZE
80	391782		RING SET, PISTON .020" OVERSIZE
80	391783		RING SET, PISTON .030" OVERSIZE
81	260924		LOCK, PISTON PIN
82	394661		PISTON ASSEMBLY, STANDARD
82	394662		PISTON ASSEMBLY .010" OVERSIZE
82	394663		PISTON ASSEMBLY .020" OVERSIZE
82	394664		PISTON ASSEMBLY .030" OVERSIZE
83	222299		LOCK, CONNECTING ROD SCREW
84	92909		SCREW, CONNECTING ROD
85	490348		ROD ASSEMBLY, CONNECTING
87	66538		ELBOW, SPARK PLUG
88	293918		PLUG, SPARK RESISTOR
89	93723		SCREW, CYLINDER HEAD 3"
90	299691		PIN ASSEMBLY, PISTON, STANDARD
90	391286		PIN ASSEMBLY, PISTON .005" OVER
91	491491		HEAD, CYLINDER
92	94160		PIN, ECCENTRIC
93	262243		ECCENTRIC
94	491323		SEAL, GOVERNOR
95	491255		LABEL KIT
96	67218		CONNECTOR, FUEL PIPE






Ref #	Part Number	Qty	Description
4	73680600		SUB= 73690600
5	19111216		WASHER M
6	72140505		BOLT
20	73680500		SUB= 73690500
23	72140506		BOLT
37	17490612		SCREW
50	72140606		BOLT
67	72140610		BOLT.3/8-14X1.25



Ref #	Part Number	Qty	Description
31	73680600		SUB= 73690600
70	17490612		SCREW
71	17490508		SCREW LT
92	71011012		SCREW.HXHD.10-2
93	73661000		NUT.FLANGE
96	730536K		SUB= 100536K
97	74760612		SUB= 74780612
98	73680500		SUB= 73690500



Ref #	Part Number	Qty	Description
6	74760416		BOLT
7	10040400		LOCKWASHER
8	17210806		SCREW
25	104757X		HUB CAP
38	19131312		WASHER
53	73680600		SUB= 73690600
65	17080408		SCREW
66	17490624		SCREW LT
67	11050600		LOCKWASHER
68	74760612		SUB= 74780612
69	74760616		BOLT
70	72140606		BOLT
79	10040600		LOCKWASHER
83	17021008		SCREW
89	72140506		BOLT
90	7368050		NUT CROWN LOCK

**F F**



**129**



**130**

**G G**



**67**



**70**

**H H**



**76**



**125**



**70**

**I I**



**96**



**70**

**B B**



**123**



**124**


**K K**



**113**

Ref #	Part Number	Qty	Description
62	110854X		SUPPORT RH YTH
67	74760612		SUB= 74780612
70	73680600		SUB= 73690600
76	74760616		BOLT
89	73680400		SUB= 73690400
96	74760612		SUB= 74780612
113	121144X		SUB= 127018X
123	1200068X		SUB= 120068X
124	19171912		WASHER
126	19131614		WASHER
129	11030400		LOCKWASHER GT
130	73490400		SUB= 146525






Ref #	Part Number	Qty	Description
7	73680600		SUB= 73690600
10	105848X		"BOLT, SHOULDER LT"
14	110739X		WASHER T
15	73980600		NUT SPECIAL T
36	72140606		BOLT
40	74780624		"BOLT,HEX"

### 12 H.P. HYDROSTATIC YARD TRACTOR


#### LIFT ADJUSTMENT



Ref #	Part Number	Qty	Description
1	121891X		HDLE ADJ LIFT
2	73360700		NUT
3	110729X		ROD LIFT LT
4	76020308		SUB= 3145
5	2876H		SPRING T
6	19131016		WASHER
8	19151216		WASHER
9	110810X		TRUNION LT
11	109413X		GRIP
12	105723X		SUB= 125925X
13	121002X		SUB= 123096X
16	4939M		SUB= 85902
17	121006X		LEVER ROD LT
18	4921H		SPRING.RETAINER
19	19171516		WASHER T
20	11029X		SUB= 110029X
21	121031X		SHAFT YTH
22	110448X		PIVOT PIN T
23	110447X		SUB= 132793
24	73710700		NUT LOCK YTH
25	12000037		KLIP RING
26	105864X		"BRACKET, SUSPE T"
28	121598X		RH SUSP ARM ASM
29	9135R		SPRING H
30	106308X		SUB= 130171
32	7322080		NUT, HEX FIN. 1/2 - 13
33	121599X		LH SUSP ARM ASM
34	12000022		E-RING
37	19292016		WASHER
38	110807X		NUT T
39	73350600		NUT

### 12 H.P. HYDROSTATIC YARD TRACTOR


#### MOWER



Ref #	Part Number	Qty	Description
1	106085X		BELT-V.79.1.MWR
2	108672X		SUB= 144726
3	8417J		SUB= 128772
4	73680600		SUB= 73690600
5	19111216		WASHER M
7	105896X		SUB= 137607
8	110452X		NUT PUSH M
9	106734X		SUB= 123713X
10	106735X		ROD-HINGE T
11	106736X		DEFLECTOR-SHLD T
12	108682X		NLA
13	105304X		CAP-SLEEVE LT
14	105662X		LINK.PARALLEL
15	105744X		"ROD, FRT. PARAL T"
16	4921H		SPRING.RETAINER
18	109835X		HINGE PIN T
20	73680500		SUB= 73690500
21	109598X		BRACKET RH LT
22	109597X		BRACKET LH T
24	109820X		DECAL YT
25	109503X		SUPPORT ARM T
26	109504X		STOP T
27			REFER TO IMAGE
29	74760637		SUB= 74930632
30	108674X		SUB= 127162X
31	106902X		SPACER RETAINER
32	121316X		PULLEY IDLER
33	106513X		"WASHER, WEAR LT"
35	121687X		"JACKSHAFT.38""LT"
36	100668L		SUPPORT PLATE LT
39	121263X		"BLADE.38"" HI-LI"
40	19132012		WASHER
41	10030600		SUB= 10040600
42	74610624		BOLT.3/8-24X1-1/2
43	102727X		"SPRING.EXT.8.5""
54	105857X		"BRKT,SUSP RH T"
55	108673X		"BRKT,SUSP REAR LH"
63	19111016		WASHER
65	7631J		RUNNER-LH M
68	121349X		DECAL WARNING
69	19131316		WASHER
75	19131210		WASHER
76	110445X		SUPPORT T
77	109776X		PIVOT PIN T
78	109729X		ROLLER T
79	19151610		WASHER T
80	19161616		WASHER
81	74760512		BOLT
82	76020412		COTTER PIN
83	73680500		SUB= 73690500
84	109646X		BRACKET LH T
85	109647X		BRACKET RH T

### 12 H.P. HYDROSTATIC YARD TRACTOR

#### PUMP



Ref #	Part Number	Qty	Description
1	122756X		SHAFT.PU.2003022
2	122716X		RETAINIANG RING-(2003016)
3	122745X		BALL BEARING
4	122715X		SPACER
5	122700X		SEAL LIP
6	122699X		RING.RET.2003052
8	122767X		CRADLE BEARING (2003023)
9	122729X		PLUG
10	122746X		O RING
11	122747X		BEARING
12	122717X		SEAL.9008000-0126
13	122748X		TRUNION ARM (2003005)
14	122749X		GUIDE.2000015.HYD
15	122768X		SUB= 121430X
17	122769X		JOURNAL BRG(2003071)
16	122770X		SUB= 142936
18	122771		SUB= 122771X
19	122772X		CENTER SECTION
20	122773X		NEEDLE BEARING
21	122722X		LIP SEAL-9008000-0127
22	122750X		SHAFT
23	122774X		WASHER
25	122775X		SUB= 121430X
26	122776X		SUB= 121430X
27	122777X		SUB= 121430X
28	122778X		SUB= 121430X
29	122779X		SUB= 121430X
30	122723X		SEAL LIP
31	122780X		CYLINDER BLOCK
32	122781X		CYLINDER BLOCK(70331)
33	122782X		PISTON
34	122784X		PISTON SPRING
35	122785X		WASHER.TR.2003019
37	122786X		PIN
38	122718X		GASKET.20030600
39	122731X		FILTER
40	122730X		WASHER (2000011)
41	122728X		SPRING
42	122706X		PLUG
43	122705X		O RING
44	122702X		BALL
45	122704X		SPRING.2003012.HY
46	122787X		PLUG
47	122752X		SCREW9007314-0808
48	122753X		SCREW
50	122788X		WASHER
51	122789X		PIN
52	122754X		PLUG
53	122711X		O RING
54	122708X		SPRING
55	122709X		SUB= 122712X
56	122712X		BYPAS KT 25130011
57	122710X		O RING (9004175-0027)
58	122727X		ADHESIVE LABEL
59	122790X		PLUG
60	122791X		SPRING
	121430X		PUMP.BDU-10S-114






---

Ref #	Part Number	Qty	Description
			REFER TO IMAGE

---

### 12 H.P. HYDROSTATIC YARD TRACTOR

#### STEERING ASSEMBLY




Ref #	Part Number	Qty	Description
1	122202X		DECAL, STEERING WHEEL INSERT
2	100710L		INSERT-WHEEL LT
3	73940800		SUB= 73360800
4	100712K		WASHER
5	100713N		SUB= 150547
6	100711L		ADAPTER LT
7	106945X		TUBE YT
8	106943X		SPACER LT
9	4921H		SPRING.RETAINER
10	102670X		SPRING GTV
12	73610600		SUB= 7810H
13	104757X		HUB CAP
14	121274X		KNOB.DUCKHEAD.1/2
15	110845X		ROD.YTH
16	121631X		SPRING TORSION
17	108196X		BRKT CONTROL HYT
18	109557X		STEERING SHAFT T
19	2882J		DRIVE PIN
20	74580		SHAFT SPACER LT
21	71208		BUSHING
22	109432X		SUB= 110150X
23	19212016		WASHER D
24	12000029		RING
25	6266H		WASHER .T
26	108683X		ROD STEERING T
27	1089972X		SUB= 108972X
28	108684X		GEAR.SECTOR.HYT
29	106126X		KEY-WOODRUFF LT
30	76020412		COTTER PIN
31	73680600		SUB= 73690600
32	108200X		WASHER FRIC HYT
34	108518X		BOLT HYT
35	19212016		WASHER D
36	108201X		SPACER HYT
37	121202X		LINK CONTROL
38	108844X		SPRING HYT
39	19132012		WASHER
40	74760648		BOLT - HEX 3/8 - 16 X 3
41	121209X		ARM ASM PUMP
42	105663X		SUPPORT-SADDL T
43	74761060		BOLT LT
44	105664X		SUPPORT.SADDLE.FT
45	105727X		LINK-DRAG LT
46	10040600		LOCKWASHER
47	10040500		LOCKWASHER
48	121334X		ROD TIE
49	73810500		NUT.LOCK.5/16-24
50	105656X		SPINDLE-LH LT
51	19272016		WASHER
52	110438X		BEARING
53	6266H		WASHER .T
54	3366R		COL. SRTG. BEAR.
55	73901000		"NUT-LOC,FLANGE LT"
56	108075X		FRONT AXLE
57	105654X		SUB= 130524
58	278H		FITTING LT
59	65139		VALVE STEM LT
60	59192		VALVE CAP

Ref #	Part Number	Qty	Description
61	9040H		"FLANGE, BEARING"
63	106222X		SUB= 122073X
65	108212X		TRUNION HYT
66	121750X		ROD ADJ CONTROL
73	6855M		ZERK M
74	121748X		WASHER
75	5320R		INSUL CLIP T
77	108685X		GEAR PINION T
78	109816X		NYLINER T
79	101930X		WASHER YTV
81	19131212		WASHER T
82	121749		SUB= 121749X
83	19111216		WASHER M
84	19151516		WASHER
85	110739X		WASHER T
86	121232X		CAP
87	121217X		GUIDE CONTROL
88	121216X		BRKT
89	17490512		SCREW
90	17021008		SCREW
91	19070816		WASHER
94	121204X		BELLCRANK
95	121206X		BRKT BELLCRANK
99	121190X		KEEPER

### 12 H.P. HYDROSTATIC YARD TRACTOR

#### TRANSAXLE




Ref #	Part Number	Qty	Description
1	122614X		HSG HALF LH-44077
2	122615X		HSG HALF RH-44076
3	122616X		AXLE LH -44273
4	122620X		AXLE RH-44272
5	122621X		BEARING.44121.AGR
6	122622X		WASHER -44008
7	122623X		GEAR MITER -44096
8	122624X		GEAR MITER -44097
9	122625X		NUT -44133
10	122626X		SHAFT CROSS
11	122688X		SCREW-STUD -44271
12	122629X		SNAP RING -44146
13	122631X		"THRUST, BEARING -44128"
14	122633X		HOUSING.ASM.DIFF.-62590
15	122634X		"FLANGE, BEARING-44129"
16	122640X		GEAR
17	122641X		BOLT -44126
18	122642X		SHAFT INPUT-44270
19	122643X		SNAP RING -44145
20	122644X		RET RING (44144)
21	122645X		SUB= 155892
22	122646X		"NEEDLE, BEARING 44099"
23	122647X		BEARING.NEE.44139
24	122648X		WASHER-44109
25	122649X		KEY.44136.HYDRO
26	122650X		SCREW
27	122651X		SUB= 155892
28	122652X		WASHER -44125
	122653X		WASHER -44150
	122654X		WASHER-44151
29	122656X		PIN COTTER -44101
30	122658X		NUT -44142
31	122659X		WASHER FLAT -44130
32	122660X		ARM BRAKE 23710
33	122662X		PIN BRAKE ACTUATO -44127
34	122663X		BRAKE YOKE
35	122664X		DISC BRAKE -(44090)
36	123065X		KEY -44143
37	122666X		SCREW -44277
38	122667X		PLATE PUCK -44134
39	122668X		SUB= 142883
40	123066X		SCREW -44300
41	122670X		SCREW -44123
42	122671X		SCREW -44124
43	122672X		"BALL, BEARING -44147"
44	122673X		"BALL, BEARING -44232"
45	122674X		SHAFT PINION 44083
46	122675X		SHAFT DRIVE-44080
47	123059X		NEEDLE BEARING -44342
48	123060X		THRUST.BRONZE -44343
49	122654X		WASHER-44151
50	122689X		SPACER -23711
51	121839X		COUPLING- 44084
52	122681X		SUB= 126975X
53	122682X		NUT -43178
54	122683X		PINION-DR.44079
55	122684X		BOLT SQ HD
56	122685X		WASHER -44278

Ref #	Part Number	Qty	Description
57	122686X		WASHER -44137
58	122687X		PIN ROLL-44269
59	122678X		NLA
	123061X		WASHER -44371
60	123062X		DOWEL PIN -44346
61	123063X		SEAL GREASE -44394
	121431X		TRANSAXLE.AGRIFAB



### 12 H.P. HYDROSTATIC YARD TRACTOR TRANSAXLE AND PUMP ASSEMBLY



Ref #	Part Number	Qty	Description
1	121192X		SUB= 123634X
2	76020312		SUB= 3145
3	121193X		SUB= 123634X
4	121188X		BRACKET
5	74780412		SUB= 74780414
6	121186X		FAN
7	121180X		PULLEY TRANSAXLE
8	121211X		STANDOFF
9	121182X		GUARD ASSY
10			REFER TO IMAGE
11			REFER TO IMAGE
12	74760572		BOLT
13	121323X		PUMP.2003081.
14	73680500		SUB= 73690500
15	121250X		SPRING
16	74760612		SUB= 74780612
17	73680600		SUB= 73690600
18	10040500		LOCKWASHER
19	71673		PLUNGER CAP T
20	7605J		BOLT T
21	120529X		WASHER T
22	73680400		SUB= 73690400
23	19092016		WASHER
24	10040400		LOCKWASHER