


# REPAIR PARTS / PIÈCES DE RECHANGE

GRASS CATCHER - NUMBER QCT38-97 (96072000100)  
RAMASSE-HERBE - NUMÉRO QCT38-97 (96072000100)



# REPAIR PARTS / PIÈCES DE RECHANGE

GRASS CATCHER - NUMBER QCT38-97 (96072000100)  
 RAMASSE-HERBE - NUMÉRO QCT38-97 (96072000100)

KEY PART NO.	DESCRIPTION	DESCRIPTION	KEY PART NO.	DESCRIPTION	DESCRIPTION
2	532069180	Nut, Crownlock #10-24	21	532132796	Spring, Cover L.H. (black)
3	532127533	Screen, Cover	22	532133235	Spacer, Cover
4	532171061	Cover Asm. (Incl. 3,38,39)	23	532132983	Spring, Cover R.H. (gray)
5	532126840	Chute, Upper	24	532180923	Support Assembly
6	818021008	Screw, Special	25	873800400	Locknut 1/4-20
7	532130933	Full Bag Indicator	26	532124670	Spring, Retainer
8	532087175	Screw, #10-24 x 1-1/8	27	872140405	Bolt
9	819061216	Washer 3/16x3/4x16 Ga.	28	532179745	Bracket, Stop
10	532007206	Spacer, Split	31	532174083	Plug, Tubing End
11	532060867	Nut, Acorn #10-24	32	532179746	Bagger, Frame
12	810071000	Washer, lock	33	532192786	Pin, Hinge
13	532109808	Latch, Chute	34	532127534	Gasket, Cover
14	532125004	Nut, Weld	35	532183286	Container, Top
15	532160793	Latch Assembly, Hook	36	532129586	Container, Bottom
18	532192574	Chute, Lower	38	532130895	Latch Handle, Cover
20	871081010	Screw #10-24 x 5/8	39	532155042	Strip, Reinforcement
			—	532194915	Owner's Manual