


# SECTION 10: PARTS LIST FOR MODEL 849




# Model 849

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1.	720-0294	Foam Handle	49.	714-0507	Cotter Pin
2.	747-0824	Blade Control Handle	50.	736-0278	Flat Washer
3.	731-1023	Rear Discharge Chute Assembly	51.	731-1488	Rear Flap
4.	710-1270	Oval C-Sunk Screw	52.	726-0240	Cable Tie
5.	746-0883	Control Housing	53.	17065A	Belt Guard Housing: Lower
6.	712-0324	Hex Lock Nut	54.	710-1025	Hex Screw #12 x 1.25"
7.	731-0924	Shift Lever: 3 Speed	55.	753-0609	Blade Adapter Kit
8.	731-0906	Mounting Cover: Speed Cable	56.	742-0741	21" Mulching Blade
9.	710-1205	Rope Guide	57.	731-1343	Mulch Plug
10.	720-0279	Wing Nut	58.	736-0524A	Blade Bell Support
11.	720-0249	Hub Cap: Euro Gray	59.	710-1044	Hex Bolt 3/8-24 x 1.5"
12.	710-0896	Truss Machine Screw	60.	712-0266	Jam Nut
13.	736-0258	Flat Washer	61.	748-0190	Spacer
14.	749-0439D	Upper Handle: Short Deluxe	62.	712-3020	Lock Nut
15.	16129A	Panel Support Bracket	63.	710-1005	Hex B-TT Screw
16.	16862	Rear Catcher Panel	64.	16136C	Handle Mounting Bracket RH
17.	17095A	Rear Discharge Door	65.	16137C	Handle Mounting Bracket LH
18.	738-0705	Shoulder Screw	66.	710-0260	Carriage Bolt
19.	732-0483A	Torsion Spring	67.	710-0607	Hex Tap Screw 5/16-18
20.	747-0514	Pivot Pin	68.	710-0654A	Hex Tap Screw 3/8-16
21.	710-0134	Carriage Bolt	69.	712-3010	Hex Nut 5/16-18
22.	710-0924	Truss Machine Screw	70.	720-0223	Grip
23.	726-0272	Clamp	71.	732-0606	Height Adjustment Lever
24.	738-0704	Shoulder Bolt	72.	747-0684	Shift Rod
25.	710-0751	Hex Bolt 1/4-20 x 0.62"	73.	736-0242	Bell Washer
26.	712-0287	Hex Nut 1/4-20	74.	750-0736	Spacer
27.	736-0270	Bell Washer 1/4"	75.	750-0624	Shoulder Spacer
28.	736-0329	Lock Washer 1/4"	76.	719-0279	Rope Guide
29.	747-0705	Front Grass Catcher Frame	77.	732-0481	Extension Spring
30.	722-0139	Foam Strip	78.	782-0521	Lever Connection Arm
31.	732-0627	Shift Lever Spring	79.	741-0486B	Bearing 1/2" ID
32.	741-0491	Flanged Bearing	80.	748-0188B	Pawl LH
33.	712-0397	Wing Nut w/ Washer	81.	748-0381	Pawl RH
34.	746-0710A	Speed Cable	82.	634-0020	Wheel Assembly
35.	749-0907B	Lower Handle	83.	726-0175	Clamp
36.	711-0805	Shoulder Pin	84.	738-0137A	Shoulder Screw
37.	738-0234	Shoulder Screw	85.	736-0526	Spring Washer
38.	664-0097	Grass Bag	86.	748-0358	Crankshaft Spacer
39.	736-0108	Flat Washer	87.	731-0880	Panel Clip
40.	750-0968	Spacer	88.	712-0414	Weld Lock Nut
41.	736-0204	Flat Washer	89.	731-1137	Flanged Bushing
42.	17055B	Chain — Axle Assembly	90.	736-0504	Wave Washer
43.	710-0352	Hex Tap Screw 1/4" x 0.38"	91.	720-0276	Hand Knob
44.	736-0232	Wave Washer	92.	756-0613	Pulley Half: Variable Speed
45.	710-0776A	Hex Tap Screw 1/4" x 0.62"	93.	756-0611	Pulley Half: Variable Speed
46.	738-0234	Shoulder Screw	94.	710-0578	Machine Screw 1/4-20
47.	712-0296	Hex Lock Nut 3/8-24	95.	731-0904A	Upper Housing
48.	713-0353	#48 Chain .500" Pitch x 30 Links	96.	754-0343	V-Belt

# Model 849

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
97.	712-0271	Sems Nut 1/4-20	129.	746-0912	Control Cable: 44"
98.	731-0801	Bag Handle	130.	748-0318	Ratchet Wheel
99.	731-0620	Drive Clutch Control Lever	131.	738-0875	Front Axle
100.	714-0104	Hairpin Clip	132.	712-0711	Hex Jam Nut
102.	16859A	Cutting Deck	133.	731-0884	Side Discharge Chute
106.	711-0313	Sleeve	134.	741-0522	Hex Flange Bearing
107.	712-0291	Lock Nut	136.	106228	Plastic Spacer: Ratchet
108.	732-0306	Compression Spring	138.	17053A	Chain Cover
109.	17070	Cable Bracket	140.	710-0599	Hex Tap Screw
110.	682-7514	Multi-Speed Housing Assembly	144.	736-0300	Flat Washer
114.	731-0905A	Lower Housing	147.	738-0719A	Rear Shaft Assembly
115.	16864	Cable Bracket	148.	741-0324	Hex Flange Bearing
116.	713-0397	Gear: Rack	149.	736-0160	Flat Washer
117.	720-0190	Door Grip	150.	618-0055	Transmission Assembly Comp.
118.	710-1667A	C Sunk TT Screw	151.	16500A	Hex Bearing Cup
119.	732-0362	Compression Spring	152.	710-0429	Hex TT Screw #10 x 0.38"
121.	710-1174	Curved Carriage Bolt	153.	749-0764A	Rear Catcher Frame
122.	711-0805	Shoulder Pin	154.	732-0362	Extension Spring
123.	736-0169	Lock Washer	155.	736-0253	Belleville Washer

# Model 849



Ref. No.	Part No.	Description
1	710-1062	Hex Bolt 1/4-20 x 1.25"
2	726-0329	Lock Washer
3	618-0053	Upper Housing
4	713-0400	#48 Sprocket 7T
5	736-0336	Flat Washer 5/8" ID
6	741-0413	Hex Flange Bearing
7	16500A	Hex Bearing Cup
8	736-0314	Thrust Washer
9	741-0479	Thrust Bearing
11	717-1216	11T Helical Gear
12	748-0208A	Flange Bearing
13	721-0212	Oil Seal
15	756-0330A	Flange Pulley
16	736-0270	Bell Washer
17	712-0351	Hex Nut
18	738-0440	Shoulder Spacer
20	738-0826	Shoulder Bolt
21	656-0008	FI-Idler Plastic 1.5" dia.
22	741-0556	Needle Bearing
24	782-7570	Idler Bracket Assembly
25	712-0138	Hex Patch Lock Nut
26	732-0357A	Extension Spring
27	618-0054	Lower Housing
28	741-0415	Flange Bearing 0.56" dia.
29	717-0616A	Shaft Assembly
30	741-0414	Flange Bearing
31	721-0213	Oil Seal
34	710-0589	AB Screw #10-16
35	736-0410	Hex Washer
36	17718	Transmission Belt Guard
37	721-0325	Plug
38	710-0653	Hex B-Tap Screw
39	710-0599	Hex AB Tap Screw
40	710-0896	Hex B-Tap Screw
41	712-0287	Hex Nut
42	736-0270	Bell Washer
43	736-0329	Lock Washer
44	746-0710A	Self-Propelled Cable
45	747-0549	Self-Propelled Belt Guard
46	782-7569	Belt Guard
47	17064	Belt Cover
—	717-0417B	Transmission Complete