


ILLUSTRATED PARTS LIST FOR MODEL 12AS569



Model Series 569

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1.	710-1174	Carriage Bolt	37.	710-0606	Hex Screw 1/4-20 x 1.5"
2.	710-1205	Rope Guide	38.	748-0411	Blade Adapter
3.	720-0279	Wing Nut	39.	756-1146A	Drive Pulley
4.	736-0451	Saddle Washer	40.	712-0324	Hex Lock Nut
5.	720-0284	Handle Knob	41.	782-0082A	Rear Discharge Deck 21"
6.	714-0104	Hairpin Clip	42.	710-1650	Shld. Screw
7.	738-0481A	Shoulder Screw	43.	731-1936A	Transmission Cover
8.	736-0456	Flat Washer .510 I.D. x 1.373 O.D.	44.	710-1008	TT Screw
9.	736-0182	Spring Wash. .500 I.D. x 1.00 O.D.	45.	631-0075B	Engine Spacer Assembly
10.	736-0105	Bell Washer .375 I.D. x .870 O.D.	46.	711-1293	Belt Keeper Pin
11.	710-0599	Tapp Screw 1/4-20 x .500	47.	712-0271	Hex Nut 1/4-20
12.	736-0270	Bell Wash. .265 I.D. x .75 O.D.	48.	782-7599A	Grassbag Door
13.	682-7000	Mulching Plug (Hinged)	49.	710-0216	Hex Hd. Cap Scr. 3/8-16
14.	782-5004	Rear Baffle RH	50.	712-0431	Flange L-Nut 3/8-16
15.	782-5007A	Mulching Plug	51.	710-0896	AB Tap Screw 1/4-14 x .625"
16.	742-0741	Mulching Blade w/Star	52.	750-0434	Spacer
	742-0641	Standard Blade	53.	710-0286	Pan Hd. Screw 1/4-20 x .5"
17.	714-0101	Hairpin Clip	54.	747-0996	Pivot Rod
18.	736-3013	Flat Washer	55.	732-0809	Torsion Spring
19.	736-0865	Snap Ring	56.	720-0312	Foam Grip
20.	717-1762	Gear 14T RH	57.	738-0507B	Shoulder Screw
	717-1761	Gear 14T LH†	58.	732-0866	Spring Lever
21.	715-0221	Dowel Pin	59.	17489A	Pivot Bar LH†
22.	782-7551	Wheel Dust Cap		17488A	Pivot Bar RH
23.	716-0102	Snap Ring	60.	682-3058	Handle Bracket Assembly RH
24.	736-0474	Washer DD 1.5" O.D.		682-3059	Handle Bracket Assembly LH†
25.	732-0706	Front Lever RH	61.	782-5003	Rear Baffle LH†
	732-0707	Front Lever LH†	62.	710-1017	Scr. AB 1/4-14 x 0.625"
26.	720-0426	Knob	63.	682-3056A	Handle Brkt. Ass'y Comp. RH
27.	710-0216	Hex Screw	64.	682-3057A	Handlr Brkt. Ass'y Comp. LH
28.	682-0509	Pivot Plate Assembly	65.	682-0512A	Height Adjuster Ass'y Comp. RH
29.	782-0511A	Height Adj. Plate LH†	66.	682-0511A	Height Adjuster Ass'y Comp. LH
	782-0512B	Height Adj. Plate RH	67.	747-0995A	Grassbag Frame
30.	736-0447	Wave Washer	68.	664-0123	Grass Bag w/Half Sail
31.	748-0355	Bearing Support	69.	710-0501	Hex Hd. Cap Screw
32.	782-5002	Front Baffle	70.	710-0431	Saddle Washer
33.	712-0798	Hex Nut	71.	647-0070	Control Handle
34.	736-0331	Bell Washer		731-2623	Bail Cover †
35.	710-1257	Hex Bolt	72.	732-1171	Compression Spring
36.	736-0452	Bell Washer	73.	720-0428	Button

† Not shown

Model Series 569

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
74.	749-1405A	Upper Handle	92.	732-0708	Bearing Retainer
75.	746-1141	Control Cable	93.	741-0604A	Bearing Sleeve .50 I.D.
76.	731-0981A	Hub Cap	94.	715-0168	Pin
77.	734-2042	Wheel 8 x 2	95.	716-0209	Retention Spring
78.	734-2050	Wheel 14 x 2	96.	732-1172	Torsion Spring
79.	710-0703	Carriage Bolt	97.	731-2532	Control Cover LH
80.	712-0397	Wing Nut	98.	782-0156	Lever
81.	731-1236	Trail Shield	99.	731-2533	Control Cover RH
82.	732-0700	Wire	100.	747-2136	Lower Bail Handle
83.	754-0637	V-Belt	101.	710-1256	Hi-Low Screw
84.	749-0907B	Lower Handle	102.	750-1166	Sleeve Spacer LH
85.	746-0960	Drive Cable		750-1166	Sleeve Spacer RH
86.	731-1409	Chute Deflector	103.	726-0240	Cable Tie
87.	618-0657	Transmission Assembly Comp.	104.	732-1043	Belt Tension Spring
89.	747-0710	Hinge Pin	105.	715-0169	Roll Pin
90.	782-7006	Hinge Mtg. Brkt.	106.	756-1231	Input Pulley
91.	732-0731	Torsion Spring	-	737-0476	Bottle of Oil