



Ref #	Part Number	Qty	Description
1	731-0220		Steering Wheel Cap
	731-1459A		Steering Wheel Cap (Sq.-MTD)
	13AG095G118 (1997)		Steering Wheel Cap (Square-No Logo)
	731-1460		Steering Wheel Cap (Square-No Logo)
2	710-0643		Hex Bolt 5/16-18 x 1" Lg.
3	736-0242		Belleville Wash..345" I.D.
4	731-1693		Steering Wheel (3 Spoke)
	731-1687		Steering Wheel (3 Spoke)
	631-0027		Steering Wheel (4 Spoke)
5	731-0559A		Steering Bellow-4.5" (Style A)
	731-0954		Steering Bellow-9" (Style 0, 1,3, 4, 5, 6,8,9)
	731-1542		Steering Bellow-3.25" (Style 7)
6	712-0240		Hex Jam Nut 7/16-20 Thd.
7	741-0587		Flange Bearing .628" I.D. x 1.36 O.D. (Style A)
8	723-0448		Ball Joint 7/16-20 Thd.
9	17198A		Retainer Plate
10	738-0141		Shoulder Bolt .437" Dia. x .35 Lg. 5/16-18 Thd.
11	710-0152		Hex Bolt 3/8-24 x 1.0" Lg. (Gr. 5)
13	750-0535		Spacer .380" I.D. x .625" O.D. x .227
14	736-0217		L-Wash. 3/8" I.D. (H.D.)
15	710-0726		Hex Wash. Hd. Self-Tap Scr.
16	711-1107		Steering Drag Link New Part
17	783-0041A		Front Pivot Brkt.
18	738-0527		Shoulder Bolt .498" Dia. x 2.04 Lg. 3/8-16 Thd.
19	712-0431		Flanged L- Nut 3/8-16 Thd.
21	712-0411		Hex L-Nut 5/16-24 Thd.
22	16481A		Steering Arm Front Axle
23	710-0772		Hex Bolt 5/16-24 x 2.00" Lg. (Gr.5)
24	741-0659		Hex Fig. Brg..632 I.D.
25	683-0128		Pivot Bar Ass'y.
26	683-0127		Front Axle Ass'y-L.H. 15 x 6 Round and Square Shoulder
	638-0125		Front Axle Ass'y-L.H. (46" Deck) 15 x 6 Round and Square Shoulder
27	712-0241		Hex Nut 3/8-24 Thd.
28	736-0169		L-Wash. 3/8" I.D.
29	723-3018		Ball Joint 3/8-24 Thd.
30	747-0753		Tie Rod (Adjustable)
	747-0861		Tie Rod (Non-Adjustable)
31	712-0711		Hex Jam Nut 3/8-24 Thd.
32	683-0126		Front Axle Ass'y.-R.H. 15 x 6 Round and Square Shoulder
	683-0124		Front Axle Ass'y.- R.H. (46" Deck) 15 x 6 Round and Square Shoulder
33	634-0056		Wheel Ass'y. Comp. 15 x 6 Square Shoulder
	634-0105		Wheel Ass'y. Comp. 15 x 6 Round Shoulder
	734-0255		Air Valve 15 x 6 Round and Square Shoulder
	734-0864		Tire Only 15 x 6 Round and Square Shoulder
34	634-0024		Front Wheel Rim Only 15 x 6 Round and Square Shoulder
35	741-0487A		Bearing 15 x 6 Round and Square Shoulder
36	736-0285		FI-Wash..635 I.D. x 1.59" O.D.


Ref #	Part Number	Qty	Description
37	731-0484A		Front Wheel Hub Cap
	731-1787A		Spoked Hub Cap (Yellow) (Opt.) New Part
	13A0895G118 (1997)		Spoked Hub Cap (Gray) (Opt.) New Part
	734-1613A		Spoked Hub Cap (Gray) (Opt.) New Part
	734-1612A		Spoked Hub Cap (Beige) (Opt.) New Part
38	714-0470		Cotter Pin 1/8" Dia. x 1.25"
39	736-0531		FI-Wash..640" I.D. x 1.24" O.D.
40	726-0214		Push Cap 5/8" Dia. Rod
42	712-0262		Hex Jam Nut 3/8-24 Thd.
43	710-1309		Hex Patch Bolt 5/16-18 x .62"
44			UNKNOWN
46	748-0389		Cap
47	712-0214		Hex Cent. L-Nut 3/8-24 Thd.
48	736-0169		L-Wash. 3/8" I.D.
49	712-0158		Hex Cent. L-Nut 5/16-18 Thd.
50	736-0119		L-Wash. 5/16" I.D.
51	717-0622A		Steering Gear Segment
52	741-0656		Hex Fig. Brg..634 I.D. New Part
53	736-0187		FI-Wash. (Hardened)
54	738-0919		Steering Shaft New Part
57	710-0837		Oval Hd. Cr.-Sunk Scr.#10 x 5/8" Lg. (Style A)
58	736-0271		Wave-Wash..32" I.D. x .62" O.D.
59	736-0187		FI-Wash. (Hardened)
60	723-0448		Drag Link Ball Joint 7/16-20 Thd.
61			UNKNOWN
63	727-0425A		Spring Clip (Used w/Spiked Hub Cap)
64	736-0356		Bell-Wash..39" I.D. x 1.38" O.D.
65	731-1291A		Pivot Bar End Cap (Optional) New Part
66	710-0459		Hex Bolt 3/8-24 x 1.5" Lg. (Gr. 5)
69	731-1649		Axle Cap
70	731-0955		Steering Wheel Insert (Optional)



Ref #	Part Number	Qty	Description
1	783-0103		Connecting Rod
2	6830039A		Pivot Link Ass'y.-L.H.
3	6830028A		Pivot Link Ass'y.-R.H.
4	17710		Deck Lift & Hanger Assembly
5	14800A		Deck Hanger Link Ass'y.
6	14804A		Deck Hanger Link Ass'y.
7	748-0331		Shld. Spacer .318" I.D.
8	736-0264		FI-Wash..344" I.D. x .62" O.D.
9	736-0119		L-Wash. 5/16" I.D.
10	712-3010		Hex Nut 5/16-18 Thd. (Gr. 5)
12	714-0470		Cotter Pin 1/8" Dia.
13	736-0256		FI-Wash..635" I.D. x 1.0" O.D.
14	683-0003		Height Adj. Stop Lever Ass'y. (Incl. Ref. 15)
15	08540		Knob Optional Parts
16	710-0604		Hex Wash. TT-Tap Scr.5/16-18 x .75" Lg.
17	748-0176		Flange Brg..63" I.D. Optional Parts
18	710-1238		Hex Wash. Hd. Scr. 5/16-18x .875" Lg.
19	710-0118		Hex Bolt 5/16-18 x .75" Lg.
20	17730		Index Brkt.
21	783-0042A		Upper Frame-R.H.
23	736-0267		FI-Wash..385" I.D. x .87" O.D.
24	736-0160		FI-Wash..531" I.D. x .93" O.D.
25	726-0272		Clamp
26	738-0526		Running Board Rod
27	710-3007		Hex Wash. Hd. Tap Scr.
28	14802A		Link Deck Lift Ass'y.
29	711-0723A		Adj. Ferrule 3/8-24 Thd.
30	17712		Adj. Deck Lift Link
31	712-3066		Hex Nut 1/2-20 Thd. (Gr. 5)
32	711-0841		Lift Link Adjuster
33	17637A		Lift Shaft Ass'y.
34	725-1657A		Safety Switch (Deck)
35	714-0145		Inter. Cotter Pin 3/8" Dia.
36	732-0637		Extension Spring
37	17636C		Stabilizer Bracket New Part
38	738-0670		Shaft 1/2" Dia. x 10.28" Lg.
39	732-0638		Extension Spring
40	720-0233		Grip (Lift Handle)
41	97675A		Deck Lift Handle Ass'y.
42	738-0669		Shaft 3/8" Dia. x 9.34" Lg.
43	747-0598		Disengagement Rod
44	97624		Stabilizer Shaft Ass'y.
45	732-0556		Extension Spring 7.58" Lg.
46	783-0043		Upper Frame-L.H.
47	741-0313		Flange Brg..632" I.D.
48	17128A		Spring Retainer Brkt.
49	716-0104		"E"-Ring
50	736-0425		Bell-Wash..325" I.D.
55			UNKNOWN




Ref #	Part Number	Qty	Description
2	710-1260		Hex Wash. Hd.TT-Tap Scr. 5/16-18 x .75" Lg.
3	683-0141		42" Deck Ass'y. New Part
	3A0695G118 (1997)		42" Deck Ass'y. Comp. New Part; (For Service
	753-0698		Deck, Chute and Spindle Assembly (Part 2) Only)
4	783-0149		Belt Guard Deck New Part
7	712-0291		Hex L-Nut 1/4-20 Thd. Optional
8	710-0258		Hex Bolt 1/4-20 x .62"
10	711-0792		Hinge Pin
13	712-0181		Hex Top L-Nut 3/8-16 Thd.
14	712-3006		Hex Nut 1/4-20 Thd. (Gr. 5)
17	734-0973		Deck Wheel-5"
18	736-0105		Bell-Wash..40" I.D. x .88" O.D.
22	738-0373		Shld. Bolt .498" Dia. x 1.53"
23	742-0616		3 in 1 Blade New Part
26	754-0371A		V-Belt
27	736-0270		Bell-Wash. 1/4" I.D.
28	783-0342		Brake Disc
33	710-0157		Hex Bolt 5/16-24 x .75" Lg.
35	712-0417A		Hex Flange Nut 5/8-18 Thd.
37	736-0158		L-Wash. 5/8" I.D.
39	618-0142		Blade Spindle Ass'y. Comp. New Part; (Incl. Ref. 28, 35, 42)
42	756-0980		5.75" Dia. Pulley New Part
52	703-1693		Hinge Mtg. Brkt.
53	732-0602		Torsion Spring
54	726-0106		Push Nut
55	731-1032		Chute Ass'y. Comp. (Incl. Ref. 10, 52, 53, 54, 55)
56	710-0597		Hex Bolt 1/4-20 x 1" Lg. Optional
57	712-3087		Wing Nut 1/4-20 Thd. Optional
58	731-1643		Mulching Plug New Part; Optional
59	16606		Retainer Hook Brkt.
60	712-0271		Hex Sems Nut 1/4-20 Thd.
61	710-0258		Hex Bolt 1/4-20 x .62" Lg.



Ref #	Part Number	Qty	Description
1	732-0750A		Spring Switch New Part
2	712-0265		Hex Sems Nut 5/16-18 Thd.
3	736-095G118 (1997)		Index Bracket New Part
4	731-1774		Driver Frame/Pedal Assembly/Wheels, Rear
5	710-0924		Pan Hd. Mach. Scr. 1/4-20 x .75"
6	710-0599		Hex Wash. Hd. TT-Tap Scr.
7	712-0138		Hex Nut 1/4-28 Thd.
8	736-0329		L-Wash. 1/4" I.D.
10	710-0195		Hex Bolt 1/4-28 x .62" Lg.
11	783-0310C		Lower Frame Ass'y. New Part
14	725-1426		Solenoid
15	736-0222		Ext. L-Wash. 1/4" I.D.
17	750-0956		Spacer
18	756-0983		Engine Pulley
19	711-1044		Belt Guard Stud 4.75" Lg.
20	736-0322		FI-Wash. 7/16" I.D. x 1.25" O.D.
21	736-0171		L-Wash. 7/16" I.D.
22	710-0757		Hex Bolt 7/16-20 x 1.5" Lg.
23	735-0196		Foot Pad
24	683-0049		Brake Lockout Brkt. Ass'y.
26	732-0728		Foot Pedal Return Spring
27	738-0296		Shld. Bolt .437" Dia. x .268"
28	736-0406		FI-Wash. 7/16" I.D. x 1-3/8" O.D.
29	747-0608A		Lock-up Rod New Part
30	17755A		Bracket
31	736-0119		L-Wash. 5/16" I.D.
32	712-0267		Hex Nut 5/16-18 Thd.
33	720-0166		Ball Knob
34	732-0727		Neutral Return Spring
35	712-0273		Hex Nut 5/16-24 Thd.
36	736-3078		FI-Wash. .344" I.D. x 1" O.D.
37	783-0092		Scissor-Flat
38	736-0362		FI-Wash. .33" I.D. x 1.25" O.D.
39	750-0808		Spacer
40	736-0219		Bell-Wash, .4" I.D. x 1.13" O.D.
41	761-0196		Friction Washer
42	750-0918		Centering Gauge Spacer
43	783-0095		Neutral Return Mtg. Brkt.
44	736-0270		Bell-Wash. .265" I.D. x .75" O.D.
45	732-0718		Comp. Spring 1,19" Lg.
46	736-3092		FI-Wash. .26" I.D. x .72" O.D.
47	712-0123		Hex Nut 5/16-24 Thd.
48	710-0299		Hex Bolt 1/4-28 x 1" Lg. (Gr. 5)
49	710-1012		Rib Neck Bolt 5/16-24 x .84" Lg.
50	783-0093		Scissor-Offset
51	747-0887		Neutral Return Rod
52	738-0879		Friction Disc Stud
53	748-0368		Shld. Spacer
54	783-0096		Neutral Return Lever
55	736-3092		FI-Wash. .265" I.D. x 1" O.D.
56	736-0329		L-Wash. 1/4" I.D.
57	712-0287		Hex Nut 1/4-20 Thd.
58	714-0104		Hairpin Clip
59	736-0262		FI-Wash. .375" I.D. x .87" O.D.
60	736-0413		Spring Wash. .39" I.D.


Ref #	Part Number	Qty	Description
61	712-0116		Hex L-Nut 3/8-24 Thd.
62	712-0711		Hex Jam Nut 3/8-24 Thd.
63	783-0099A		Neutral Return Brkt.
64	711-0832		Ferrule 3/8-24 Thd.
65	747-0365		Control Rod
66	723-0351		Ball Joint 3/8-24 Thd.
67	748-0234		Shld. Spacer.5" Dia. x .27" Lg.
68	736-0159		R-Wash. .349" I.D. x .879" O.D.
69	710-3007		Hex Tap Scr. #12 x 3/8" Lg.
70	731-1449		Fan
71	712-0333		Hex Nut 1/2-20 Thd.
72	736-0921		L-Wash. 1/2" I.D.
73	712-0241		Hex Nut 3/8-24 Thd.
74	736-0169		L-Wash. 3/8" I.D.
75	756-0975		Transmission Pulley
76	732-0729		Wire Ring
77	754-0441		V-Belt
78	756-0981		FI-Idler Pulley 2.75" O.D.
79	720-0238		Rod End Grip
80	747-0894		Bypass Control Lever
81	783-0085		Transaxle Support Brkt.--L.H.
82	710-0528		Hex Bolt 5/16-18 x 1.25" Lg.
83	732-0384		Ext. Spring 6.12
84	683-0051		Idler Brkt. Ass'y.
85	710-0116		Hex Bolt 5/16-18 x 2.5" Lg.
86	710-0118		Hex Bolt 5/16-18 x .75" Lg.
87	748-0234		Shld. Spacer .5" Dia. x .27" Lg.
88	783-0086A		Transaxle Support Brkt.--R.H.
89	747-0886		Brake Rod 24.94" Lg.
90	732-0716		Ext. Spring
91	747-0893		Bypass Actuator Rod
92	736-0142		FI-Wash. .281" I.D. x .5" O.D.
93	783-0098		Bypass Adjustment Brkt.
94	736-0222		External L-Wash. 1/4" I.D.
95	731-1086A		Sleeve .758" I.D. x 1" O.D.
96	710-0604		Hex . TT-Tap Scr. 5/16-18 x .62"
97	17994		Retainer Brkt.-Transaxle
98	710-0176		Hex Bolt 5/16-18 x 2.75" Lg.
	710-3195		Hex Bolt 5/16-18 x 4.5" Lg. (Used w/46" Deck)
99	732-0250		Tension Spring
100	710-0888		Hex Bolt 5/16-24 x 1" Lg.
101	710-0224		Hex Wash. Hd. AB-Tap Scr.
107	647-0008A		Speed Control Lever Ass'y.
108	17668		Axle Support Brkt.-R.H.
	17669		Axle Support Brkt.-L.H.
109	732-0433		Ext. Spring 2.75" Lg.
110	736-0141		Spr-Wash. .445" I.D. x .75" O.D.
111	17840		Transaxle Mtg. Brkt.
112	725-1657A		Safety Switch (Clutch)
115	710-0650		Hex TT-Tap Scr. 5/16-18 x .75"
116	683-0123		Clutch/Brake Pedal Ass'y. New Part
117	750-0802		Spacer .63" I.D.
118	17860		Pedal Bracket
119	736-3008		FI-Wash. .344" I.D. x .75" O.D.

Ref #	Part Number	Qty	Description
120	714-0111		Cotter Pin 3/32" Dia.
121	714-0470		Cotter Pin 1/8" Dia.
122	736-0149		R-Wash. .385" I.D. x .62" O.D.
123	710-0227		Hex AB-Tap Scr. #8 x .5" Lg.
124	726-0320		Insulator Nut Plate
125	725-1643		Reverse Safety Switch
126	725-1399		Extension Wire
127	710-0520		Hex Bolt 3/8-16 x 1.5" Lg.
128	756-0116		Idler Pulley
129	736-0280		FI-Wash. .39" I.D.
130	712-0798		Hex Nut 3/8-16 Thd.
131	720-0218		Shift Knob
133	731-1481		Vent Cap
134	731-1480		Plastic Vent
135	726-0324		Clamp
136	721-0330		O-Ring
137	731-1485		Hose Fitting
138	751-0588-18		Fuel Line 18" Lg.
139	710-0627		Hex Bolt 5/16-24 x .75" Lg.
140	736-0242		Bell-Wash. .345" I.D. x .88" O.D.
141	734-0255		Air Valve
142	634-0070		Rim Only 20" x 8" (Round and Square Shoulder)
143	734-1675		Wheel Ass'y. Comp. (Round Shoulder)
	734-1696		Tire Only (Round Shoulder)
143	634-0104		Wheel Ass'y. Comp. (Square Shoulder)
	734-1730		Tire Only (Square Shoulder)
144	734-1615A		Hub Cap (Gray) (Optional)
	734-1614A		Hub Cap (Beige) (Optional)
	734-1788A		Hub Cap (Yellow) (Optional)
145	727-0425A		Spring Clip
146	783-0099		Idler Bracket
147	710-1315		Hex TT-Tap Scr. 3/8-16 x 1.25"
148	750-0258		Spacer .32" I.D. x .75" O.D. (Used w/46" Deck)




Ref #	Part Number	Qty	Description
1	629-0125		Harness Adapter (Alt.)
2	629-0208		Harness Adapter
3	629-0302A		Wire Harness w/Light Switch & Amp New Part
4	725-0267		Ignition Switch W/O Light Switch & Amp New Part
5	725-0634		Light Switch
6	725-0925		Ammeter
7	725-0963		Bulb
8	725-1426		Solenoid
9	725-1643		Safety Switch (Reverse)
10	725-1657A		Safety Switch
11	725-1711		Wire Retainer Clip
12	726-3046		Ratchet


13AG695G118 (1997)
Electrical/Switches



Ref #	Part Number	Qty	Description
1	783-0250		Hood
2	738-0952		Shld. Bolt .375" Dia. x .125" Lg.
6	712-0274		Hex Sems Nut 1/4-20 Thd.
8	731-1099A		Headlight Lens w/o Logo
	731-1767		Headlight Lens w/ Logo New Part
9	712-3027		Flange L-Nut 1/4-20 Thd.
10	731-1097D		Grille
11	736-3078		FI-Wash..344" I.D. x 1" O.D.
12	712-0267		Hex Nut 5/16-18 Thd.
13	725-0963		Lamp
14	725-1649		Socket
15	710-0703		Carriage Bolt 1/4-20 x .75" Lg.
16	710-0599		Hex Wash. Hd. TT-Tap Scr.1/4-20 x .5" Lg.
17	736-0173		FI-Wash..281" I.D. x .73" O.D.
18	726-0233		Bolt Retainer 1/4" I.D.
19	712-0185		Speed Nut 1/4-20Thd.
20	710-0118		Hex Bolt 5/16-18 x .75" Lg.
21	17632A		Gas Tank Support Brkt.
22	731-1096B		Dash w/Ammeter Hole
	731-1337A		Dash w/o Ammeter Hole
23	725-0267		Ignition Switch
24	725-0201		Ignition Key
25	746-0616A		Choke Control 23" Lg.
	746-0614A		Choke Control 38" Lg.
	746-3021		Choke Control 29" Lg.
	746-0720		Choke Control 20" Lg.
26	725-0634		Light Switch Optional Parts
27	725-0925		Ammeter Optional Parts
32	710-0286		Truss Mach. Scr. 1/4-20 x .5" Lg.
35	17871B		Fender w/Cutout
38	710-0726		Hex Wash. Hd. AB-Tap Scr.5/16 x .75" Lg.
41	831-0823A		Throttle Box Ass'y.
42	710-0779A		Truss Mach. AB-Tap Scr.#10 x .5" Lg.
43	746-0776		Throttle Control Wire 18.5" Lg.
	746-0634		Throttle Control Wire 35" Lg.
	746-0638		Throttle Control Wire 22" Lg.
44	777-9206		Grille Reflector Label
45	710-0603		Hex Wash. Hd. B-Tap Scr.5/16-18 x .5" Lg.
46	17782		Choke Retainer
47	710-0642		Hex TT-Tap Scr. 1/4-20 x .75" Lg.
49	783-0150A		Side Panel-R.H.
50	783-0151		Side Panel-L.H.
71	726-0211		U-Nut 5/16-18 Thd.
72	710-0286		Truss Mach. Scr. 1/4-20 x .5" Lg.
73	736-0342		FI-Wash..283" I.D. x .75" Lg.
74	732-0835		Hood Latch Optional Parts
75	712-0272		Hex Sems Nut 10-24 Thd. Optional Parts
76	710-0473		Truss Mach. Scr. 10-24 x .5" Lg. Optional Parts




Ref #	Part Number	Qty	Description
1	710-0148		Hex Tap Scr. #8-32 x .38" Lg.
2	710-0599		Hex Wash. TT-Tap Scr. 1/4-20 x 5" Lg.
3	710-0604		Hex Wash. TT-Tap Scr. 5/16-18 x .62" Lg.
4	710-0779A		Truss Mach. Scr. #10 x .5" Lg.
5	710-1315		Hex Hd. Tap Scr. 3/8-16 x 1.25" Lg.
6	710-3015		Hex Bolt 1/4-20 x .75" Lg.
7	712-0271		Hex Sems Nut 1/4-20 Thd.
9	721-0346		Exhaust Gasket
10	726-0205		Hose Clamp
11	726-0272		Clamp
12	736-0329		L-Wash. 1/4" I.D.
13	736-3067		FI-Wash..188" I.D. x .438" O.D.
14	737-0143		Oil Drain Cap
15	737-0164		Pipe Nipple 3/8 x 18 NPT.
17	751-0535-26		Fuel Line 26" Lg.
18	751-0564		Deflector: Muffler
19	751-0616		Muffler
20	751-0623		Exhaust Pipe-L.H.
21	751-0624		Exhaust Pipe-R.H.
22	783-0320A		Muffler Bracket New Part
23	783-0357		Heat Shield



Ref #	Part Number	Qty	Description
2	710-1208		Hex Tap Scr. 5/16-18 x 3.25"
3	938-0155		Screw
5	936-0141		Washer
6	783-0039A		Seat Pivot Bracket New Part
7	751-0603		Fuel Cap
8	751-0553		Fuel Tank (12.5 H.R & Smaller)
	751-0555		Fuel Tank (13 H.P. & Larger)
9	726-0209		Tie Strap
10	751-0535-15		Fuel Line
11	726-0205		Hose Clamp
13	712-0287		Hex Nut 1/4-20 Thd.
14	736-0329		L-Wash. 1/4" I.D.
16	732-0735		Compression Spring
21	738-0526		Running Board Rod
22	710-0227		Hex AB-Tap Scr. #8 x .50" Lg.
23	726-0139		Speed Nut #10Z
24	783-0041A		Front Pivot Brkt.
25	710-0870		Hex Tap Scr. 3/8-16 x .62" Lg.
26	710-0726		Hex Wash. Hd. AB-Tap Scr.5/16 x .75" Lg.
28	710-0134		Carriage Bolt 1/4-20 x .62"
29	17770B		Running Board (R.H. & L.H.)
30	761-0168A		Blade Brake Ass'y.
32	731-0909		Rubber Foot Pad-L.H. Optional Parts
	731-0910		Rubber Foot Pad-R.H. Optional Parts
	723-0422		Abrasive Foot Pad Optional Parts
33			UNKNOWN
34	783-0310C		Lower Frame New Part
36	726-0278		Insulator Boss Plate
37	736-0264		FI-Wash. .344" I.D. x .625" O.D.
38	710-0118		Hex Bolt 5/16-18 x .75" Lg.
39	783-0042A		Upper Frame-R.H.
42	732-0581B		Extension Spring 5.31" Lg.
44	725-1707B		12-V Battery
45	783-0043		Upper Frame-L.H.
46	783-0133B		Shift Cover New Part
48	726-0279		Insulator Plate
49	17951		Seat Pivot Brkt. Support-L.H.
50	783-0355A		High Plate New Part
51	712-0267		Hex Nut 5/16-18 Thd.
52	736-0119		L-Wash. 5/16" I.D.
53	17239A		Seat Lift Brkt.
54	757-0363		Seat 8-7/8" High
	757-0364		Seat 8-7/8" High (Yellow)
	757-0360		Seat 10-5/8" High
	757-0365		Seat 10-5/8" High (Yellow)
	757-0350		Seat 14-1/4" High
	757-0372		Seat 14-1/4" High (Yellow)
55	17950		Seat Pivot Brkt. Support-R.H.
56	738-0296		Shld. Bolt .437" Dia. x .268"
57	725-1303		Spring Switch (Seat-Outer)
59	710-0650		Hex TT-Tap Scr. 5/16-18 x 7/8"
63	725-1439		Safety Switch (Seat-Inner)
65	783-0345		Battery Tray
66	710-0351		Truss Mach. B-Tap Scr.#10 x .5" Lg.

Ref #	Part Number	Qty	Description
67	748-0347		Spring Spacer
68	710-0323		Truss Mach. Scr. 5/16-18 x .75"
69	710-0118		Hex Bolt 5/16-18 x .75" Lg.
70	731-0405		Snap Bushing
71	723-3064		Battery Retainer Strap
72	712-3010		Hex Nut 5/16-18Thd.
73	712-0265		Hex Sems Nut 5/16-18 Thd.
74	712-0271		Hex Sems Nut 1/4-20 Thd.

3AG695G118 (1997)
 Seat/Frame/Battery/Fuel Tank



Ref #	Part Number	Qty	Description
1	718-0255A		Transmission Comp.
2	HG-9008000-0128	1	Seal-Lip
3	HG-9008000-0126	1	Seal-Lip
4	HG-45074	1	Seal-Lip 10x 25x7
5	HG-50126	1	Arm-Bypass
6	HG-44870	1	Ring-Retting
7	HG-44094	1	Arm-Actuating
8	HG-44891	2	Pin-Actuating
9	HG-50108	1	Nut-Hex Lock 5/16-24 UNJC
10	HG-44130	1	Washer 7/16" x 7/8" x .06"
11	HG-50042	1	Breather Ass'y.
12	HG-45007	1	Arm-Control
13	HG-50034	1	Puck-Dampener
14	HG-50018	1	Set Screw
15	HG-50129	1	Strap, Locking