



Ref #	Part Number	Qty	Description
2	710-1260		Hex Wash. Hd. TT-Tap Scr. 5/16-18 x .75" Lg.
3	683-0141 3AR616G190 FST-16 (1997) 812-0697 42" Mowing Deck		42" Deck Ass'y. Page 2 of 26 42" Deck Ass'y. Comp. (For Service Only) Code: N Notates a new part (not previously existing)
4	783-0149		Belt Guard Deck Code: N Notates a new part (not previously existing)
7	712-0291		Hex L-Nut 1/4-20 Thd. Optional
8	710-0258		Hex Bolt 1/4-20 x .62"
10	711-0792		Hinge Pin
13	712-0181		Hex Top L-Nut 3/8-16 Thd.
14	712-3006		Hex Nut 1/4-20 Thd. (Gr. 5)
17	734-0973		Deck Wheel - 5"
18	736-0105		Bell-Wash. .40" I.D. x .88" O.D.
22	738-0373		Shld. Bolt .498" Dia. x 1.53"
23	742-0616		3 in 1 Blade
26	754-0373A		V-Belt
27	736-0270		Bell-Wash. 1/4" I.D.
28	783-0342		Brake Disc
35	712-0417A		Hex Flange Nut 5/8-18 Thd.
39	618-0142		Blade Spindle Ass'y. Comp. (Incl. Ref. 28, 35, 42)
42	756-0980		5.75" Dia. Pulley
52	703-1693		Hinge Mtg. Brkt.
53	732-0602		Torsion Spring
54	726-0106		Push Nut
55	731-1032		Chute Ass'y. Comp. (Incl. Ref. 10, 52, 53, 54, 55)
56	710-0597		Hex Bolt 1/4-20 x 1" Lg. Optional
57	712-3087		Wing Nut 1/4-20 Thd. Optional
58	731-1643		Mulching Plug Optional
59	16606		Retainer Hook Brkt.
60	712-0271		Hex Sems Nut 1/4-20 Thd.
61	710-0258		Hex Bolt 1/4-20 x .62" Lg.




Ref #	Part Number	Qty	Description
1	683-0132		Parking Brake Lockout Brkt. Ass'y.
2	712-0265		Hex Sems Nut 5/16-18 Thd.
3	736-0406	13 AR616G190 FST-16 (1997)	FI-Wash. .442" I.D. x 1.38" O.D.
4	712-0298		Hex Nut 5/16-24 Thd.
11	783-0310B		Lower Frame Ass'y.
13	712-0287		Hex Nut 1/4-20 Thd.
14	736-0329		L-Wash. 1/4" I.D.
15			UNKNOWN
19	711-1044		Belt Guard Pin
20	714-0118		Sq. Key 1/4" x 1/4" x 1.5"
21	756-0639		Engine Pulley
23	736-0171		L-Wash. 7/16" I.D.
24	710-0561		Hex Bolt 7/16-20 x 2.5" Lg.
25	754-0280		Variable Speed Belt
26	710-0118		Hex Bolt 5/16-18 x .75" Lg.
27	17963		Bearing Shaft Bracket Ass'y.
28	741-0419		Flanged Nyliner Brg. .63" I.D. x .6" Lg.
29	712-0241		Hex Nut 3/8-24 Thd.
30	17834		Idler Bracket
31	736-0169		L-Wash. 3/8" I.D.
32	783-0232		U-Bracket
33	783-0233		Transaxle Support Brkt.
34	732-0556		Ext. Spring .94" O.D. x 7.58"
35	714-0149B		Inter. Cotter Pin
36	750-0802		Spacer .63" I.D.
37	714-0470		Cotter Pin 1/8" Dia. x 1.0" Lg.
38	710-0603		Self-Tap Scr. 5/16-18 x .5" Lg.
39	736-0108		FL-Wash. .51" I.D. x .75"
43	710-0599		Hex Wash. Hd. S-Tap Scr. 1/4-20 x .50" Lg.
44	683-0123		Clutch/Brake Pedal Ass'y.
45	720-0218		Shift Knob
46	710-0351		Truss Mach. B-Tap Scr. #10 x .5" Lg.
48	735-0196		Foot Pad
49	717-1459		Electric Clutch
51	747-0774		Shift Lever Rod
52	738-0296		Shld. Bolt .437"
53	732-0656		Ext. Spring 3.6"
54	711-0832		Ferrule
55	710-3056		Hex Bolt 5/16-18 x 3.25"
59	710-0195		Hex Bolt 1/4-28 x .62" Lg.
60	618-0034		Transaxle Complete
61	712-0291		Hex L-Nut 1/4-20 Thd.
62	711-0768		Belt Guard Pin 1/4-20 Thd.
63	736-0275		FI-Wash. .34" I.D. x .68" O.D.
64	710-1026		Hex Wash. TT-Tap Scr. 1/4-20 x 1.75"
65	732-0568		Ext. Spring 2.59" Lg.
66	732-0428A		Ext. Spring .5" O.D. x 4.35"
67	16554A		Variable Speed Torque Brkt. Ass'y.
68	741-0419		Flanged Bearing
69	714-0507		Cotter Pin 3/32" Dia.
70	748-0234		Shoulder Spacer .27" Lg.
71	747-0530		Speed Control Link
72	741-0405		Truss Bearing .56 Dia. x 1.25"
73	720-0166		Ball Knob

Ref #	Part Number	Qty	Description
74	756-0437		FI-Idler Pulley 3.25" x .75"
75	756-0950		"V"-Pulley
76	736-0921		L-Wash. 1/2" I.D.
77	712-0922		Hex Jam Nut 1/2-20 Thd.
78	710-0539		Hex Bolt 3/8-24 x 1.75" Lg.
79	754-0370		Variable Speed Belt
80	716-0114		Snap Ring .56" Dia.
81	736-0355		FI-Wash. .56" I.D. x 1.0" O.D.
82	717-0800A		Variable Speed Pulley Ass'y. 5" O.D. Code: N Notates a new part (not previously existing)
84	16354B		Variable Speed Brkt. Ass'y.
85	732-0525		Comp. Spring - Clip
86	17668		Axle Support Brkt.- R.H.
	17669		Axle Support Brkt.- L.H. (Not shown)
89	17839		Speed Cont. Rod Brkt.
90	736-0414		Teflon Washer .565" I.D.
93	725-1657A		Safety Switch (Clutch) Code: N Notates a new part (not previously existing)
94	738-0755		Shld. Bolt 3/8-24 x 3.12" Lg.
97	736-0105		Bell-Wash. .38" I.D. x .88"
98	738-0837		Shaft
99	736-0331		Bell-Wash. .39" I.D. x 1.12"
100	736-0256		FI-Wash. .64" I.D. x .94"
101	714-0111		Cotter Pin 3/32" Dia. x 1" Lg.
102	710-0650		Hex Wash. Hd. Scr. 5/16-18 x .62" Lg.
103	710-0728		Hex Wash. Hd. AB-Tap Scr. .75" Lg.
104	17755A		Bracket
107	14624D		Pedal Bracket Code: N Notates a new part (not previously existing)
108	714-0507		Cotter Pin 3/32" Dia. x .75"
109	711-0198		Ferrule
111	710-0909A		Hex Wash. Tap Scr.
112	736-0270		Bell-Wash. .265" I.D. x .75"
113	17832		Shift Lever Link Ass'y.
115	736-0140		FI-Wash. .385" I.D. x .62"
116	741-0404	2 Req'd.	Needle Bearings
118	710-1223		Hex Bolt 1/4-20 x 3.5" Lg.
119	710-0427		Hex Bolt 3/8-16 x 1.25" Lg.
123	738-0155		Shld. Bolt .437" Dia. x .162"
124	17794		Brake Rod Ass'y.
138	747-0768		Shift Lever Ass'y.
139	17767		Shift Lever Support Brkt.
140	17768		Speed Selector Lever Ass'y.
142	747-0608A		Brake Lockout Rod
143	17840		Transaxle Mtg. Brkt.
144	714-0474		Cotter Pin 1/8" x 3/4" Lg.
145	747-0771		Speed Selector Rod
146	732-0429A		Ext. Spring 3.97" Lg.
147	750-0470		Spacer .326" I.D. x .47"
148	736-0167		FI-Wash. 5/8" I.D. x 1.25"
149	717-0772A		Actuating Arm
150	736-0140		FI-Wash. .385" I.D. x .62" O.D.





Ref #	Part Number	Qty	Description
1	629-0132		Wire Harness (Monitor)
3	629-0307A 13AK616G190 FST-16 (1997) Electrical System		Wire Harness Code: N Notates a new part (not previously existing)
5	721-0342		Gasket - Relay
6	625-0634		Light Switch
7	725-0893		PTO Switch
8	725-0925		Ammeter
9	725-0963		Bulb (Headlight)
11	725-1396		Ignition Switch
12	725-1426		Solenoid
13	725-1643		Safety Switch (Reverse)
14	725-1648		Relay
15	725-1657A		Safety Switch
19	726-3046		Ratchet
	725-1365		Bulb (Monitor - Not shown)




Ref #	Part Number	Qty	Description
1	731-1429		Hood
2	710-0896		Hex Wash. B-Tap Scr. 1/4 x .62" Lg.
3	726-0232		Bolt Retainer 1/4" I.D.
4	17782		Retainer Clip
5	726-0211		U-Nut 5/16-18 Thd.
6	710-0351		Truss Mach. B-Tap Scr. #10 x .5" Lg.
7	710-0227		Hex Wash. Hd. AB-Tap Scr. #8 x .5" Lg.
8	16903A		Hood Plate
11	746-3021		Choke Control
12	712-3014		Hex Nut 1/2-27 Thd.
13	725-0893		Toggle Switch
14	16902A		Hood Hinge
15	725-0963		Lamp
16	725-1649		Twist Lock - Lamp Socket
17	777-8516		Reflector - Headlight
18	731-1147		Forward/Reverse Index Brkt.
19	731-1746		7-Speed Selector Plate
20	710-0118		Hex Bolt 5/16-18 x .75" Lg.
21	731-1430B		Grille
22	17300D		Dash Support Bracket
23	723-0416		Screen
24	712-0265		Hex Sems Nut 5/16-18 Thd.
25			UNKNOWN
26	710-0607		Hex Wash. Hd. B-Tap Scr. 5/16-18 x .5" Lg.
27	710-0429		Hex B-Tap Scr. #10 x .38" Lg.
28	736-0267		FI-Wash. 3 8" I.D. x .875" O.D.
29	711-1002		Adj. Ferrule 3/8-8 Thd.
30	783-0041A		Pivot Bar Brkt. Code: N Notates a new part (not previously existing)
32	710-0726		Hex Wash. Hd. AB-Tap Scr. 5/16 x .75" Lg.
34	714-0101		Hairpin Clip
35	716-0125		"E"-Ring .375" Dia.
36	712-0287		Hex Nut 1/4-20 Thd.
37	736-0270		Bell-Wash. .265" I.D. x .75"
38	747-0898		Adjustment Rod
39	712-0449		Hex Nut 3/8-8 Twin Thd.
40	710-3015		Hex Bolt 1/4-20 x .75" Lg.
41	720-0236		Plastic Knob
42	732-0732		Ext. Spring 3.21" Lg.
43	783-0370		Rear Fender
44	750-0755		Spacer .33" I.D. x .625" O.D.
45	710-0167		Carriage Bolt 1/4-20 x .50" Lg.
46	736-0278		FI-Wash. .328" I.D. x .68" O.D.
47	710-0599		Hex Wash. Hd. Scr. 1/4-20 x .5" Lg.
48	727-0460		indicator Strip
49	783-0120		Indicator Bracket
50	736-0119		L-Wash. 5/16" I.D.
52	750-0754		Shld. Spacer .33" I.D.
53	736-0142		FI-Wash. .281" I.D. x .5" O.D.
54	712-0158		Hex Cent. L-Nut 5/16-18 Thd.
55	731-1890		Side Cover - R.H. Code: N Notates a new part (not previously existing)

Ref #	Part Number	Qty	Description
	731-1891		Side Cover - L.H. Code: N Notates a new part (not previously existing)
	13AR616G190 FST-16 (1997)		Page 10 of 26
56	710-0934		Hood Grille And Controls
57	710-0924		Double Ended Stud 1/4-20 Thd.
58	710-0227		Truss Mach. Scr. 1/4-20 x .75" Lg.
59	831-0823A		Hex Wash Hd. AB-Tap Scr. #8 x .5" Lg.
60	746-0775		Throttle Control Box Ass'y.
61	710-0258		Throttle Control Wire 22" Lg.
62	736-0173		Hex Bolt 1/4-20 x .62" Lg.
63	725-1341B		FI-Wash. .281" I.D. x .73" O.D.
64	725-1396		Ignition Key
65	731-1510		Ignition Switch
66	725-0634		Dash Panel
67	725-0925		Light Switch
68	731-1038		Ammeter
69	725-1347		Lens
70	736-0329		Ignition Switch Cap
72	726-0320		L-Wash. 1/4" I.D.
73	725-1346		insulator Nut Plate
74	710-0779A		Ignition Switch Nut
76	725-1643		Truss Mach. AB-Tap Scr. #10 x .5" Lg.
77	710-0642		Reverse Safety Switch
80	712-0291		Hex Wash. Hd. Tap Scr. 1/4 x .75" Lg.
94	712-0147		Hex L-Nut 1/4-20 Thd.
103	17633A		Speed Nut #10-24 Thd.
104	731-0909		Gasoline Tank Support
	731-0910		Rubber Foot Pad - L.H. Code: N Notates a new part (not previously existing)
			Rubber Foot Pad - R.H. Code: N Notates a new part (not previously existing)
105	710-0599		Hex Tap Scr. 1/4-20 x .5" Lg.
111	712-0185		Speed Nut 1/4-20 Thd.
113	710-0176		Hex Bolt 5/16-18 x 2.75"
	629-0309		Headlight Harness (Not shown)




Ref #	Part Number	Qty	Description
1	710-1237		Hex Wash. Scr. #10-32 x .62" Lg.
2	710-0148		Hex Tap Scr. #8-32 x .38" Lg.
3	710-0599		Hex Wash. TT-Tap Scr. 1/4-20 x .5" Lg.
4	710-0604		Hex Wash. TT-Tap Scr. 5/16-18 x .62" Lg.
5	710-1314		Socket Head Scr. 5/16-18 x .62" Lg.
6	710-1315		Hex Wash. TT-Tap Scr. 3/8-16 x 1.25" Lg.
7	712-0271		Hex Sems Scr. 1/4-20 Thd.
8	721-0208		Gasket
9	726-0205		Hose Clamp
10	726-0272		Clamp
11	731-1682A		Oil Drain Sleeve Code: N Notates a new part (not previously existing)
12	736-0119		Lock Washer 5/16" I.D.
14	751-0535-12		Fuel Line 12" Lg.
15	751B213146		Casing Clamp
16	751-0564		Muffler Deflector
17	751-0617		Muffler
18	751-0619		Exhaust Pipe
19	783-0320A		Muffler Brkt. Code: N Notates a new part (not previously existing)
20	783-0385		Shield Brkt.

3AL616G190 FST-16 (1997)
Muffler And Exhaust



Ref #	Part Number	Qty	Description
2	710-1208		Hex Wash. Hd. Tap Scr. 5/16-18 x 3.25" Lg.
3	738-0155		Shld. Bolt .437" Dia. x .162" Page 14 of 26
4	732-0166		Seat, Lower Frame And Fuel Tank
5	736-0141		Spr-Wash. .445" I.D. x .75
6	783-0039A		Seat Pivot Bracket
7	751-0603		Fuel Cap
8	751-0574A		Fuel Tank
	749-0934		Fuel Tank Support Rod (Not shown)
9	726-0209		Tie Strap
10	751-0535-15		Fuel Line
11	726-0205		Hose Clamp
13	712-0287		Hex Nut 1/4-20 Thd.
14	736-0329		L-Wash. 1/4" I.D.
16	732-0735		Compression Spring
21	738-0526		Running Board Rod
22	710-0227		Hex Hd. AB-Tap Scr. #8 x .50"
23	726-0139		Speed Nut #10Z
24	783-0041A		Front Pivot Brkt.
25	710-0870		Hex Tap Scr. 3/8-16 x .62" Lg.
26	710-0726		Hex Wash. Hd. AB-Tap Scr. 5/16 x .75" Lg.
29	17770B		Running Board (R.H. & L.H.)
28			UNKNOWN
30			UNKNOWN
32	731-0909		Rubber Foot Pad - L.H.
	731-0910		Rubber Foot Pad - R.H.
33	710-0323		Truss Mach. Scr. 5/16-18 x .75" Lg.
34	783-0310B		Lower Frame
35	736-0169		L-Wash. 3/8" I.D.
36	726-0278		Insulator Boss Plate
37	736-0264		FI-Wash. .344" I.D. x .625" O.D.
38	710-0118		Hex Bolt 5/16-18 x .75" Lg.
39	17830B		Upper Frame - R.H.
41	712-0798		Hex Nut 3/8-16 Thd.
42	732-0581B		Extension Spring 5.31" Lg.
44	725-1707C		12-V Battery Code: N Notates a new part (not previously existing)
45	17831A		Upper Frame - L.H.
46	783-0133A		Shift Cover Code: N Notates a new part (not previously existing)
47	725-1643		Reverse Safety Switch
48	726-0279		Insulator Plate
49	17951		Seat Pivot Brkt. Support - L.H.
50	783-0355		Hitch Plate
51	712-0267		Hex Nut 5/16-18 Thd.
52	736-0119		L-Wash. 5/16" I.D.
53	17239A		Seat Lift Brkt.
54	757-0370A		Seat
55	17950		Seat Pivot Brkt. Support - R.H.
56	738-0296		Shld. Bolt .437" Dia. x .268"
57	725-1303		Spring Switch (Seat)
59	710-0650		Hex Wash. TT-Tap Scr. 5/16-18 x 7/8" Lg.
62	726-0320		Insulator Nut Plate
63	725-1439		Safety Switch (Seat)


Ref #	Part Number	Qty	Description
65	783-0345		Battery Tray
66	710-0351		Truss Mach. B-Tap Scr. #10 x 5"
67	748-0347		Spring Spacer
68	710-1221		Pan Hd. Cutting Scr. 5/16-18 x .75" Lg.
69	710-0118		Hex Bolt 5/16-18 x .75" Lg.
70			UNKNOWN
71	723-3064		Battery Retainer Strap
72	712-3010		Hex Nut 5/16-18 Thd. (Gr. 5)
73	712-0265		Hex Sems Nut 5/16-18 Thd.
74	712-0271		Hex Sems Nut 1/4-20 Thd.




Ref #	Part Number	Qty	Description
1	731-1509A		Steering Wheel Cap
2	710-0643		Hex Patch Bolt 5/16-18 x 1" Lg.
3	736-0242		Belleville Wash. .345" I.D.
4	731-1686		Steering Wheel
5	731-0954		Steering Bellow
6	738-0943		Upper Steering Shaft
9	17198A		Retainer Plate
10	738-0141		Shoulder Bolt .437" Dia. x .35" Lg. 5/16-18 Thd.
11	710-0152		Hex Bolt 3/8-24 x 1.0" Lg. (Grade 5)
13	750-0535		Spacer .380" I.D. x .625" O.D. x .227"
14	736-0169		L-Wash. 3/8" I.D.
15	710-0726		Hex Wash. Hd. Self-Tap Scr.
16	711-1107		Steering Drag Link Code: N Notates a new part (not previously existing)
17	783-0041A		Pivot Bar Brkt.
18	738-0527		Shoulder Bolt .498" Dia. x 2.04" Lg. 3/8-16 Thd.
19	712-0798		Nut 3/8-16 Thd.
21	712-0411		Hex Cent. L-Nut 5/16-24 Thd.
22	683-0055		Steering Arm Front Axle
23	710-0772		Hex Bolt 5/16-24 x 2.00" Lg. (Grade 5)
24			UNKNOWN
25	719-0342		Pivot Bar Ass'y.
26	683-0127		Front Axle Ass'y.- L.H.
27	712-0241		Hex Nut 3/8-24 Thd.
28	712-0446		Hex Jam Nut 3/8-24 Thd.
29	723-0448		Ball Joint 7/16-20 Thd. Code: N Notates a new part (not previously existing)
30	747-0753		Tie Rod
31	712-0711		Hex Jam Nut 3/8-24 Thd.
32	683-0126		Front Axle Ass'y.- R.H.
33	634-0059		Wheel Ass'y. Comp.
	734-0864		Tire Only
34	634-0051		Front Wheel Rim Only
	734-0255		Air Valve
	737-0280		Grease Fitting
35	741-0569		Ball Bearing
36	736-0285		FI-Wash. .635" I.D. x 1.59" O.D.
37	734-1783A		Front Hub Cap Code: N Notates a new part (not previously existing)
	734-1784A		Rear Hub Cap Code: N Notates a new part (not previously existing)
38	714-0470		Cotter Pin 1/8" Dia. x 1.25" Lg.
39	736-0187		FI-Wash. .640" I.D. x .24" O.D.
40	726-0214		Push Cap
43	710-1309		Pan Hd. Bolt 5/16-18 x .63" Lg.
44	736-0119		L-Wash. 5/16" I.D.
45	736-0343		FI-Wash. .33" I.D. x 1.25" O.D.
46	748-0389		Cap
49	712-0158		Hex L-Nut 5/16-18 Thd.
51	717-1701		Steering Gear Segment
52	741-0656		Hex Flg. Brg. .634 I.D.
54	618-0114		Steering Box Ass'y. Comp.

Ref #	Part Number	Qty	Description
58	736-0271		Wave Wash. .32" I.D. x .62"
61	736-0607		Ext. L-Wash. 5/16" I.D.
63	723-0425A		Spring Clip
65	17778A		Horizontal Cross Bracket
66	783-0369		Vertical Mounting Bracket Code: N Notates a new part (not previously existing)
67	710-0412		Hex Bolt 1/4-28 x .75" Lg.
68	712-0123		Hex Nut 5/16-24 Thd.
69	710-0253		Hex Bolt 3/8-16 x 1.0" Lg.
70	736-0270		Bell-Wash. .265" I.D. x .75"
71	712-0138		Hex Nut 1/4-28 Thd.
72	710-0157		Hex Bolt 5/16-24 x .75" Lg.
73	717-1466		Pinion Shaft
74	717-1461		Steering Shaft Splined Coupler
75	712-0262		Hex L-Nut 3/8-24 Thd.
76	723-0420		Rod End 3/8-24 Thd.- R.H.
77	723-0421		Rod End 3/8-24 Thd.- L.H.
78	710-0459		Hex Bolt 3/8-24 x 1.5" Lg. (Gr. 5)
79	750-0535		Spacer .38" I.D. x .625"
80	750-0809		Shld. Spacer .51" I.D.
81	736-0105		Bell-Wash. .38" I.D. x .88"
82	747-0761		Tie Rod
83	710-0191		Hex Bolt 3/8-24 x 1.25" Lg.
84	712-0296		Hex Patch L-Nut 3/8-24 Thd.
85	736-3027		FI-Wash. .531" I.D. x 1.75"
86	736-0253		Bell-Wash. .505" I.D. x 1.0"
87	17764		Steering Boom
88	738-0838		Steering Link
89	710-3181		Hex Bolt 1/2-13 x 1.5" Lg. (Gr. 5)
90	734-0255		Air Valve
91	734-1607		Rim Only
92			UNKNOWN
93	710-1142		Hex Bolt 1/2-20 x 1.75" Lg. (Gr. 5)
94	734-1668		Rear Wheel Ass'y. Comp.
	734-1596		Tire Only
95	736-0343		FI-Wash. .33" I.D. x 1.25"
96	717-1298		Wheel Flange Ass'y.
97	736-0420		FI-Wash. 1.0" x 1.56"
98	710-0191		Hex Bolt 3/8-24 x 1.25" Lg.
99	17646		Steering Brkt.- R.H.
	17647		Steering Brkt.- L.H. (Not shown)
100	741-0558		Flange Brg. 1.0" I.D.
101	736-0445		FI-Wash. .76" I.D. x 1.5"
102	741-0547		Flange Brg. 3/4" I.D.
103	737-3001		Grease Fitting
104	717-1291		Wheel Brg. Housing
105	917-1298		Shaft
106	717-1271		Pivot Sleeve
107	717-1270		U-Joint
109	715-0208		Grooved Roll Pin 1.0" Lg.
110	717-1285		Axle Horn Ass'y.
111	736-0105		Bell-Wash. .38" I.D. x .88"
112	736-0356		Bell-Wash. .39" I.D. x 1.38"

Ref #	Part Number	Qty	Description
113	736-0140		FI-Wash. .385" I.D. x .62"
114	710-0958		Hex Bolt 1/4-20 x 1.31" Lg.
115	712-0324		Hex Ins. L-Nut 1/4-20 Thd.
116	737-3000		Grease Fitting




Ref #	Part Number	Qty	Description
1	703-1029		Bearing Cup
2	703-1031		Seal Retainer
3	711-3149A		Cam Follower
4	711-3208		Pivot Shaft
5	712-3062		Hex Jam Nut 9/16-18 Thd.
6	712-3063		Hex Crown L-Nut 5/8-18 Thd.
7	714-0474		Cotter Pin 1/8" Dia.
8	717-1048		Adjustment Plug Ass'y.
9	717-1219		Steering Arm Ass'y.
10	618-0047		Steering Hsg. Bushing Ass'y.
11	721-0260		Oil Seal
12	723-3039		Seal
13	731-3040		Ball Retainer
14	736-3029		FI-Wash. .781" I.D. x 1.25" O.D.
15	737-3001		Grease Fitting
17	611-0018		Steering Shaft Ass'y.
18	741-3022		Ball Bearing
	737-3007	4 oz. Req'	Grease #251 E.P.
	618-0114		Steering Ass'y. Comp. (Incl. Ref. Nos. 1 thru 18)



Ref #	Part Number	Qty	Description
1	717-0682		Puck Plate
2	761-0200		Brake Puck
3	717-0772A		Actuating Arm
4	736-0371		FI-Wash. 11/32" I.D. x 7/8" O.D.
5	17841A		Brake Stop Brkt.
6	710-0433		Hex Bolt 1/4-20 x .62" Lg. (Special)
7	710-0809		Hex Tap Scr. 1/4-20 x 1.25" Lg.
8	732-0863		Spring Detent
9	712-0335		Castle Nut 5/16-24 Thd.
10	714-0111		Cotter Pin 3/32" Dia. x 1" Lg.
11	718-0184		Brake Disc
12	717-1102		Shifter Ass'y.
13	717-1217		Brake Puck Holder
14	716-0175		Retaining Ring
15	717-1093		Shaft Drive
16	717-1268		Shift Collar
17	710-0653		Hex Wash. Hd. Tap Scr. 1/4-20 x .38" Lg.
18	717-1184		Drive Pin
19	717-1275		Bevel Gear Ass'y. (Incl. Ref. Nos. 17, 18, 20 and 21)
20	717-1269		Spring Retaining Plate
21	732-0590		Drive Spring
22	736-0444		FI-Wash. .915" I.D. x 1.5" O.D.
23	736-0454		FI-Wash. .915" I.D. x 1.37" O.D.
24	710-0862A		Pan Hd. Scr. 1/4-20 x .5" Lg.
25	716-0184		Snap Ring
26	711-0918		Cross Shaft
27	717-1020		Miter Gear 15T
28	717-1252		Differential Can Assembly
29	717-1254		Differential Gear Ass'y. w/Bearing
30	712-0200A		Hex Ins. L-Nut 1/2-20 Thd.
31	717-1019		Miter Gear
32	717-1197		Axle
33	750-0787		Differential Thrust Spacer
34	716-0171		Retainer Ring
35	717-1228		Input Bearing Housing
36	732-0614		Wire Ring
37	716-0108		Retaining Ring
38	717-0633		Pinion Input 14T
39	711-0861		Input Shaft
40	721-0178		Seal 5/8" I.D.
41	736-0419		Thrust Wash. .621" I.D. x 1.12"
42	741-0469		Thrust Bearing
43	736-0349		FI-Wash. 5/8" I.D. x 1.0" O.D.
44	741-0335		Needle Brg. 5/8" x 1/2" Lg.
45	715-0209		Dowel Pin
46	717-1235		R.H. Housing
47	741-0340		Sleeve Bearing 3/4" I.D.
48	741-0548		Flange Bearing .906" I.D.
49	717-0796		Sq. Head Bolt 5/16-24 Thd.
50	717-1234		L.H. Housing
51	741-0124		Ball Bearing .669" I.D.
52	710-3006		Set Screw 5/16-18 x 3/8" Lg.

Ref #	Part Number	Qty	Description
53	736-0445		FI-Wash. .76" I.D. x 1.5" O.D.
54	741-0343		Brake Actuating Pin
55	741-0862		Ball Detent
56	732-0545		Ext. Spring 1.14" Lg.
57	741-0552		Differential Flange Brg.
	618-0034		Transaxle Complete



Ref #	Part Number	Qty	Description
1	783-0103		Connecting Rod
2	683-0029A		Pivot Link Ass'y.- L.H.
3	683-0028A		Pivot Link Ass'y.- R.H.
4	17710		Deck Hanger Link Ass'y.
5	14800A		Deck Hanger Link Ass'y.
6	14804A		Deck Hanger Link Ass'y.
7	748-0331		Shld. Spacer .318" I.D.
8	736-0264		FI-Wash. .344" I.D. x .62" O.D.
9	736-0119		L-Wash. 5/16" I.D.
10	712-0271		Sems Nut 1/4-20 Thd.
12	714-0470		Cotter Pin 1/8" Dia.
13	736-0256		FI-Wash. .635" I.D. x 1.0" O.D.
16	710-0604		Hex Wash. TI-Tap Scr. 5/16-18 x .75" Lg.
17	748-0176		Flange Brg. .63" I.D.
18	710-1238		Hex Wash. Hd. Scr. 5/16-18 x .875" Lg.
19	710-0118		Hex Bolt 5/16-18 x .75" Lg.
20	783-0185		Index Brkt.
21	17830B		Upper Frame - R.H. Code: N Notates a new part (not previously existing)
23	736-0267		FI-Wash. .385" I.D. x .87" O.D.
24	736-0160		FI-Wash. .531" I.D. x .93" O.D.
25	726-0272		Clamp
26	738-0526		Running Board Rod
28	14802A		Link Deck Lift Ass'y.
30	17712		Adj. Deck Lift Link
31	712-3066		Hex Nut 1/2-20 Thd. (Gr. 5)
32	711-0841		Lift Link Adjuster
33	17825B		Lift Shaft Ass'y.
35	714-0145		Inter. Cotter Pin 3/8" Dia.
36	732-0637		Extension Spring
37	17636B		Stabilizer Bracket
38	738-0670		Shaft 1/2" Dia. x 10.28" Lg.
39	732-0638		Extension Spring
40	720-0233		Grip (Lift Handle)
41	97675A		Deck Lift Handle Ass'y. Code: N Notates a new part (not previously existing)
42			UNKNOWN
44	97624		Stabilizer Shaft Ass'y.
45	732-0556		Extension Spring 7.58" Lg. Code: N Notates a new part (not previously existing)
46	17831A		Upper Frame - L.H.
47	741-0313		Flange Brg. .632" I.D.
48	17128A		Spring Retainer Brkt.
49	716-0104		"E"-Ring
50	736-0425		Bell-Wash. .325" I.D.
51	710-0599		Hex Wash. Hd. TT-Tap Scr. 1/4-20 x .5" Lg.
52	725-1657A		Spring Switch