


Ref #	Part Number	Qty	Description
1	17584A		Front Axle Ass'y. - R. H.
2	17585A		Front Axle Ass'y. - L. H.
3	683-0055		Steering Arm
4	710-0152		Hex Bolt 3/8-24 x 1" Lg.
5	710-0538		Hex Bolt 5/16-18 x .62" (Spec.)
6	710-0772		Hex Bolt 5/16-24 x 2" Lg.
7	723-3018		Ball Joint 3/8-24 Thd.
	723-0448		Ball Joint 7/16-20 Thd. (For model 450)
8	711-1117A		Steering Drag Link New Part
9	712-3057		Hex Lock Nut 5/16-24 Thd.
10	712-0214		Hex Nut 3/8-24 Thd. New Part
11	712-3010		Hex Nut 5/16-18 Thd. (Gr. 5)
12	712-0262		Hex Nut 5/16-24 Thd.
13	714-0470		Hex Nut 3/8-24 Thd.
14	717-0622A		Steering Gear Segment
15	723-0448		Drag Link Ball Joint 3/8-24 Thd.
16	726-0214		Push Cap
17	736-0119		Lock Washer 5/16" I.D.
18	736-0169		Lock Washer 3/8" I.D.
19	736-0187		FI-Washer .64" I.D. x 1.24"
20	736-0343		FI-Washer .340" I.D. x 1.125"
22	736-0271		Spring Washer .32" I.D. x .62"
23	736-0285		FI-Washer .635" I.D. x 1.585"
24	17198A		Retainer Plate
25	738-0141		Shld. Bolt .437" Dia. x .350"
26	738-0937		Steering Shaft
27	741-0659		Hex Flange Brg. .632" I.D.
28	747-0753		Tie Rod (Adjustable)
	747-0861		Tie Rod (Non-Adjustable)
29	750-0532		Spacer .985" I.D.
30	750-0535		Spacer .380" I.D.
31	17548		Front Pivot Bar Support Brkt.
32	17547		Rear Pivot Bar Support Brkt.
33	683-0128		Pivot Bar Ass'y. Ass'y.
35	634-0087		Front Wheel Ass'y. Comp. (15" x 6" w/Plastic Bearing)
	734-0864		Tire only (15" x 6" w/Plastic or Ball Bearing)
	634-0088		Rim only (15" x 6" w/Plastic Bearing)
	737-0211A		Grease Fitting (15" x 6" w/Plastic Bearing)
	737-0212		Grease Plug (15" x 6" w/Plastic Bearing) (Optional)
35	634-0091		Front Wheel Ass'y. Comp. (15" x 6" w/Ball Bearing)
	734-0864		Tire only (15" x 6" w/Plastic or Ball Bearing)
	634-0090		Rim only (15" x 6" w/Ball Bearing)
	737-0280		Grease Fitting (15" x 6" w/Ball Bearing) (Optional)
37	734-0255		Air Valve (15" x 6" w/Plastic or Ball Bearing)
38	741-0487A		Bearing (15" x 6" w/Plastic Bearing)
	741-0569		Bearing (15" x 6" w/Ball Bearing)
42	710-0643		Hex Lock Bolt 5/16-18 x 1" Lg. (Gr. 5)
43	741-0501		Steering Column Brg.
44	710-0837		Cr-Sunk Scr. #10 x 5/8" Lg.
45	731-1693		Steering Wheel
	731-1687		Steering Wheel (Uses Square Steering Wheel Cap)
46	731-0220		Steering Wheel Cap (Round)
	731-1459		Steering Wheel Cap w/MTD Logo (Square)
	731-1460		Steering Wheel Cap w/Private Label Logo (Square)
47	731-0484A		Hub Cap
48	731-0954		Bellow Steering Column


13AH451F352 (1997) 2 of 24
Steering Assembly/Axle/Frn.

Ref #	Part Number	Qty	Description
49	736-0242		Bell-Washer .345" I.D. x .88"
50	712-0431		Flanged Lock Nut 3/8-16 Thd.
51	738-0527		Shld. Bolt 1/2" Dia. x 2.04"
52	736-0356		Bell-Washer .39" x 1.38" O.D.
54	731-1649		Axle Cap
55	783-0255		Pivot Bar Side Plate - L.H.
56	783-0256		Pivot Bar Side Plate - R.H.
58	710-0604		Hex Washer Tap Scr. 5/16-18 x .62" Lg.
59	736-0217		Lock Washer 3/8" I.D. (H.D.)
61	741-0225		Hex Flange Bearing .634" Dia.
62	710-0459		Hex Bolt 3/8-24 x 1.5" Lg.
63	712-0711		Hex Jam Nut 3/8-24 Thd.
66	727-0425A	13AH451F352 (1987)	Spring Clip 3 of 24
67	734-1612A	Steering Assembly/Axle End	Hub Cap (Beige) New Part
	734-1613A		Hub Cap (Gray) New Part
68	710-0459		Hex Bolt 3/8-24 x 1.5" Lg.
69	712-0241		Hex Nut 3/8-24 Thd.
70	712-0158		Lock Nut 5/16-18 Thd. New Part




Ref #	Part Number	Qty	Description
1	17932		Gas Tank Support Brkt.
2	17933A		Pedestal
3	710-3025		Hex Bolt 5/16-18 x .75" Lg. New Part
4	925-0963		Bulb
5	710-0258		Hex Bolt 1/4 x .62" Lg.
6	925-1649		Socket
7	712-0267		Hex Nut 5/16-18 Thd.
8	725-0634		Light Switch (Optional)
9	751-0603		Gas Cap
10	726-0205		Hose Clamp
11	726-0209		Cable Tie
12	736-0222		Lock Washer 1/4" I.D. New Part
13	725-0267	13AH451F352 (1990) 5 of 24	Ignition Switch - 5 Pin
14	725-0201	Seat/Battery Fender Wash Pa	Ignition Key
15	751-0553		Fuel Tank
16	751-0535-15		Gas Line 15" Long
17	761-0194		Blade Brake Ass'y.
18	710-0134		Carriage Bolt 1/4-20 x .62"
19	710-0793		Ribbed Neck Bolt 3/8-24 x .8"
20	783-0039A		Seat Pivot Brkt. New Part
21	783-0354		Rear Fender
22	17704		Seat Hinge Support Brkt. - R.H.
23	17703		Seat Hinge Support Brkt. - L.H.
24	17553		Deck Lift Index Brkt.
25	725-1705C		Battery, Dry New Part
	725-1704		Battery, Wet
26	710-0817		Hex Self-Tap Screw 5/6-18 1.25" Lg.
27	710-0255		Truss Mach. Scr. 1/4-20 x .75" Lg.
28	710-0726		Hex AB-Tap Scr. 5/16 x .75" Lg.
29	710-1017		Torx Mach. AB-Tap Scr. 1/4 x .62" Lg.
30	710-0870		Hex Self-Tap Scr. 3/8-16 x .62" Lg.(Gr. 5)
31	712-0287		Hex Nut 1/4-20 Thd.
32	736-0607		External Lock Washer 5/16" I.D.
33	783-0349		Battery Tray
34	732-0588		Compression Spring
36	736-0242		Bell-Washer 5/16" I.D.
37	736-0329		Lock Washer 1/4" I.D.
38	777-9206		Label
40	736-0270		Bell-Washer .265" I.D. x .75"
41	710-0589		Screw
45	931-1097E		Grille
48	783-0250		Hood For model (450 & 470)
	17941		Hood For model (451 & 471)
49	736-0217		Lock Washer 3/8" I.D.H.D.
50	712-0241		Hex Lock Nut 3/8-24 Thd.
53	725-0308C		Foot Pad - R.H. New Part
54	725-0309C		Foot Pad - L.H. New Part
57	912-3027		Locknut
62	732-0704		Spring
65	736-0342		Washer
66	938-0952		Bolt
67	749-0914		Support
68	731-0511-81		Trim Strip 81" Lg.
72	746-0616A		Choke Control
73	831-0823A		Throttle Control Box
74	710-0779A		Truss AB-Tap Scr. #10 x .5"


Ref #	Part Number	Qty	Description
75	746-0776		Throttle Wire (B&S)
	746-0638		Throttle Wire (Tec.)
76	757-0345		Seat Assembly (Low Back)
	757-0338		Seat Assembly (Medium Back)
	757-0348		Seat Assembly (High Back)
	757-0364		Seat Assembly (Low Back-Yellow)
78	736-0159		Flat Washer .344" I.D. x .88" O.D.
79	722-0160		Bushing
83	710-0227		Hex Tap Scr. #8 x .5" Lg.
84	725-1439		Safety Switch (Inner)
85	732-0581B		Ext. Spring 5.31" Lg.
86	17239A		Seat Lift Brkt.
87	726-0278	13AH451F352 (1987) 6 of 24	Insulator Boss Plate
88	738-0155	Seat/Battery Fender/Dash P	Shld. Bolt .437" Dia. x .162" Lg.
89	738-0296		Shld. Bolt .437" Dia. x .268" Lg.
90	736-0141		Spring Washer .445" I.D. x .75"
91	710-0604		Hex Washer Hd. Scr. 5/16-18 x .62" Lg.
92	726-0279		Insulator Plate
94	723-0423		Center Foot Pad (Optional)
95	725-1303		Safety Switch (Outer)
96	731-1228		Dash Panel (w/Amp & Light switch)
	731-1502		Dash Panel (w/o Amp & Light switch)
97	17782		Retainer Clip
99	926-0130		Nut
100	914-0104		Pin
101	931-1099A		Lens
	931-1767		Lens w/Logo
102	725-0925		Ammeter (Optional)
103	712-3007		Hex Jam Nut 5/16-18 Thd.
104	710-0599		Hex Washer Hd. Tap Scr. 1/4-20 x .5".
105	726-0211		U-Nut 5/16-18 Thd.
106	736-0222		Ext. Lock Washer 1/4" I.D.
107	710-3015		Hex Bolt 1/4-20 x .75" Lg.
108	712-0271		Hex Sems Nut 1/4-20 Thd.
111	723-0444		Battery Strap
112	725-0689		Battery Cap




Ref #	Part Number	Qty	Description
2	710-1260		Hex Washer: TT-Tap Scr. 5/16-18 x .75" Lg.
3	683-0119		38" Deck Assembly: w/Wheels
	813-04244		38" Deck Assembly (For service only)
4	783-0343		Belt Guard, Deck: 5" Dia.
7	712-0291		Hex Lock Nut 1/4-20 Thd.
8	710-0258		Hex Bolt 1/4-20 x .62"
10	711-0792		Hinge Pin
13	712-0181		Hex Top Lock Nut 3/8-16 Thd.
14	712-3006		Hex Nut 1/4-20 Thd. Gr. 5
17	734-0973		Deck Wheel 5"
18	736-0105		Bell Washer 0.40" I.D. x .88" O.D.
22	738-0373		Shoulder Bolt .498" Dia. x 1.53"
23	742-0610		5 in 1" Star Blade
26	754-0329A	13AH451F352 (1 Page 8 of 24)	Deck Assembly (star blade)
27	736-0270		Bell Washer 1/4" I.D.
28	783-0342		Brake Disc
35	712-0417A		Hex Flange Nut 5/8-18 Thd.
39	618-0138		Blade Spindle Ass'y. (Includes ref. 28, 35, 42)
42	756-0969		5" Dia. Deck Pulley
52	703-1693		Hinge Mtg. Bracket
53	732-0602		Torsion Spring
54	726-0106		Push Nut
55	731-1032		Chute Ass'y. Comp. (Includes ref. 10, 52, 53, 54, 55)
56	710-0597		Hex Bolt 1/4-20 x 1" Lg.
57	712-3087		Wing Nut 1/4-20 Thd.
58	731-1643		Mulching Plug
59	16606		Retainer Hook Bracket
60	712-0271		Hex Sems Nut 1/4-20 Thd.
61	710-0258		Hex Bolt 1/4-20 x .62" Lg.



Ref #	Part Number	Qty	Description
1	09322		Disc: Brake
2	16606		Retainer Hook Bracket
3	618-0271		Blade Spindle
4	683-0119		Deck Assembly w/Wheels
5	710-0258		Hex Screw 1/4-20 x .625 Gr. 2
6	710-0672		Hex Cap Screw 5/16-24 x 1.25 Gr. 5
7	710-0838		Hex Screw 5/16-24 x 1.0 Gr. 5 Sp.
8	710-1039		Hex Screw 3/8-24 x 1.0 Gr. 5 Std.
9	710-1260		Hex Wash. TT Screw 5/16-18 x .75
10	712-0181		Jam Nut 3/8-16: Top Lock
11	712-0271		Hex Sems Nut 1/4-20
12	712-0318		Hex Jam Nut 5/8-18
13	712-3057	13AH451F352 (P607) 10 of 24	Hex Nut 5/16-24 Gr. 5
14	734-0937	Deck Assembly (three hole)	Wheel Deck 3.0 x 1.38
15	736-0105		Bell Washer .401 x .807 x .063
16	736-0119		Lock Washer: 5/16 Regular Duty
17	736-0158		Lock Washer: 5/8 Regular Duty
18	736-0217		Lock Washer: 3/8 Heavy Duty
19	736-0242		Bell Washer .345 I.D. x .88 O.D. x .06
20	736-0247		Flat Washer 3/8 x 1.25 O.D.
21	736-0392		Flange Washer .320 I.D. x .750 x .140
22	736-3008		Flat Washer .344 x .75 x .140
24	738-0373		Shoulder Screw
25	742-0610		Three in One Star Blade
26	748-0300		Blade Adapter
27	754-0329A		V: Belt
28	756-0486		Deck Pulley 5" Dia.
30	783-0343		Belt Cover 5" Dia.
31	831-1032		Chute Deflector: Deck, Deep Plastic




Ref #	Part Number	Qty	Description
1	738-0143		Shoulder Bolt .5" Dia. x .34" Lg.
2	17580		Lift Handle Support Strap
3	736-0169		Lock Washer 3/8" I.D.
4	712-0798		Hex Nut 3/8-16 Thd.
5	710-0428		Hex Bolt 1/4-28 x 1.25" Lg.
6	710-0351		Hex TT-Tap Scr. 1/4-20 x 5" Lg.
7	732-0640		External Spring
8	631-0026		Grip
9	17591A		Deck Lift Handle Ass'y.
10	710-0604		Hex Washer TT-Tap Scr.
11	736-0119		Lock Washer 5/16" I.D.
12	712-0267		Hex Nut 5/16-18 Thd.
13	750-0379	13AH451F352 (2007) of 24	Spacers 3/8" I.D. x .78"
14	714-0507	Deck Lift & Hanger	Cotter Pin 3/32" Dia. x .75" Lg.
15	736-0185		Flat Washer .406" I.D. x .75" O.D.
16	714-0104		Internal Cotter Pin 5/16" Dia.
17	17597		Brake Rod Guide Ass'y.
18	747-0746		Deck Engagement Rod
19	16682		Pivot Sleeve Ass'y.
20	712-0130		Hex Lock Nut 3/8-16 Thd.
21	736-0314		Thrust Washer .382" I.D.
22	736-0116		Flat Washer .635" I.D. x .93" O.D.
23	714-0470		Cotter Pin 1/8 Dia. x 1.25" Lg.
24	712-0123		Hex Nut 5/16-24 Thd.
25	726-0272		Harness Retainer
26	712-0237		Hex Cent. Lock Nut 5/16-24 Thd.
27	17555		Deck Pivot Brkt. Ass'y. - R.H.
28	738-0281		Shld. Bolt .625" Dia. x .170" Lg.
29	17574		Deck Link Shaft Ass'y.
30	738-0667		Shaft 11.2" Lg
31	747-0745		Deck Lift Rod
32	17573A		Deck Stabilizer Brkt.
33	17554		Deck Pivot Brkt. Ass'y. - R.H.
34	17563		Connecting Link
35	736-0336		Flat Washer 5/8" I.D. x 1.0" O.D.
36	17582		Pivot Support Brkt
37	710-1012		Rib Neck Bolt 5/16-24 x .84" Lg.
38	17568		Cross Shaft Ass'y.
39	17557		Deck Pivot Brkt. Ass'y. - L.H.
40	17556		Deck Pivot Brkt. Ass'y. - L.H.
41	17581		Pivot Support Brkt. - L.H.
42	17562		Connecting Link - L.H.
43	747-0584		Lift Link 3/8-24 x 1.25" Lg.
44	97709		Adj. Lift Link Ass'y.
45	97598		Deck Lift Link Ass'y.
47	736-0192		Flat Washer .531" I.D. x .94"
48	736-0185		Flat Washer .406" I.D. x .75"
49	736-0101		Flat Washer 3/8" I.D.
50	732-0638		Ext. Spring .87" Dia.
51	732-0603		Ext. Spring 11" Lg.
52	710-3038		Hex Bolt 5/16-18 x 7/8" Lg.




Ref #	Part Number	Qty	Description
1	783-0265A		Engine Pulley Belt Guard New Part
2	712-0291		Hex Lock -Nut 1/4-20 Thd.
3	711-1044		Belt Guard Pin 5/16-18 x 4.75" Lg.
4	712-0267		Hex Nut 5/16-18 Thd.
5	736-0242		Bell-Washer .345" I.D. x .88
6	710-0286		Truss-Mach. Scr. 1/4-20 x .50"
7	711-1000		Belt Guard Pin 1/4-20 Thd.
8	736-0270		Bell-Washer .265" I.D. x .75
9	736-3072		Flat Washer 3/8" I.D. x .97" O.D.
10	749-0836A		Speed Selector Brace New Part
11	712-0138		Hex Nut 1/4-28 Thd.
12	17128A		Spring Retainer Brkt.
14	736-0235	13AH451F352 (1007) 14 of 24	Flat Washer 3/8" I.D. x 1.26" O.D.
15	17694	Drive/Frame Assembly/Pedal	Idler Bracket
16	16554A		Var. Speed Torque Brkt. Ass'y.
17	16676B		Variable Speed Brkt. Ass'y. New Part
18	17962		Switch Plate
19	710-0118		Hex Bolt 5/16-18 x .75" Lg.
20	710-0151		Hex Bolt 3/8-24 x 2.0" Lg. Gr. 5
22	710-0757		Hex Bolt 7/16-20 x 1.5" Lg.
24	711-0768		Belt Guard Pin
25	712-0241		Hex Nut 3/8-24 Thd.
27	712-0287		Hex Nut 1/4-20 Thd.
29	712-3035		Hex Jam Nut 9/16-18 Thd.
30	710-0902		Hex Bolt 3/8-24 x 3.75" Lg.
31	716-0114		Snap Ring
32	717-0800A		Variable Speed Pulley Ass'y. New Part
33	618-0166A		Transaxle Ass'y. Comp.
34	736-0607		Ext. Lock Washer 5/16" I.D.
36	732-0384		Extension Spring 6.12" Lg.
37	732-0459		Extension Spring 6.74" Lg.
38	732-0568		Extension Spring 2.59" Lg.
39	736-0117		Flat Washer .385" I.D. x .620"
40	736-0119		Lock Washer 5/16" I.D.
41	736-0169		Lock Washer 3/8" I.D.
42	736-0171		Lock Washer 7/16" I. D
43	736-0322		Flat Washer .450" I.D. x 1.25"
44	736-0329		Lock Washer 1/4" I.D.
45	736-0331		Bell-Washer .39" I.D. x 1.13"
46	736-0355		Flat Washer .56" I.D. x 1.0" O.D.
47	736-0414		Washer Teflon .565 I.D.
48	736-0427		Bell-Washer 9/16" I.D. x 1.125" O.D.
49	738-0569		Shaft .56" Dia. x 3.875" Lg.
50	741-0405		Thrust Brg. 1.25 O.D.
51	741-0419		Flanged Nyliner Brg.
52	741-0495		Nyliner Flanged Brg.
53	747-0599A		Speed Control Rod
54	750-0703		Spacer
55	754-0280		V-Belt
56	754-0281		V-Belt
57	656-0003		V-Pulley 8" Dia.
58	756-0643		Idler Pulley 3-1/8" Dia. New Part
59	756-0551		Engine Pulley 6.0" Dia. x 3.56"
61	732-0413		Extension Spring 7.08" Lg.
62	748-0234		Shld. Spacer .500" Dia.
63	734-0255		Air Valve

Ref #	Part Number	Qty	Description
64	17588B		Front Frame: Lower New Part
65	783-0180A		Rear Frame New Part
66	16654A		Transaxle Support Brkt. New Part
67	16659		Transaxle Brkt. Reinforcement
68	710-0726		Hex Washer AB-Tap Scr. 5/16 x .75" Lg.
69	710-0258		Hex Bolt 1/4_20 x .62" Lg.
70	725-1426		Solenoid
71	725-0459		Circuit Breaker
72	736-0222		External Lock Washer 1/4" I.D.
73	710-0176		Hex Bolt 5/16-18 x 2.75" Lg.
74	710-0351		Truss Mach. B-Tap Scr. #10 x .50" Lg.
75	17644A		Foot Pedal Rod Ass'y.
76	735-0239	13AH451F352 (P090)	Foot Pedal
77	710-1012	15 of 24	Drive/Frame Assembly/Pedal
80	711-0198		Ribbed Neck Bolt 5/16-24 x .84"
81	712-0271		Ferrule
82	714-0470		Hex Sems Nut 1/4-20 Thd.
83	714-0507		Cotter Pin 1/8" Dia. x 1.25" Lg.
85	714-0114		Cotter Pin 3/32" Dia. x .75" Lg.
86	736-0256		Sq. Key 1/4 x 2.0" Lg.
88	747-0593		Flat Washer .635" I.D. x 1.0"
89	750-0800		Brake Rod
90	725-0976A		Spacer 5/8" I.D. x 1.2" Lg.
91	17457B		Ground Wire 7.25" Lg.
92	16693B		Speed Selector Lever
	16694B		5 Spd. Selector Brkt. (450 Series)
93	738-0138		7 Spd. Selector Brkt. (470 Sedes)
94	711-0677		Shld. Bolt .437" Dia. x .47" Lg.
95	710-0428		Ferrule
96	714-0104		Hex Bolt 1/4-28 x 1.25" Lg.
97	750-0703		Internal Cotter Pin 5/16" Dia.
99	736-0264		Spacer .375" I.D. x .625"
100	736-0463		Flat Washer .344" I.D. x .62"
101	747-0675A		Flat Washer .25" I.D. x .62" O.D.
102	736-0133		Speed Control Rod
103	714-0115		Flat Washer 3/8" I.D. x 1.25" O.D.
104	736-0275		Cotter Pin 1/8" Dia. x 1.0" Lg.
105	736-0278		Flat Washer .34" I.D. x .68"
106	710-0627		Flat Washer .34" I.D.
107	734-0817		Hex Lock Bolt 5/16-24 x .75" Lg.
108	734-0448		Rear Wheel Ass'y. Comp.
109	634-0070		Tire Only
110	736-0242		Rear Wheel Rim Ass'y. Only
113	712-0298		Bell-Washer .345" I.D. x .88"
114	17178A		Hex Jam Nut 1/4-20 Thd.
115	17839		Shift Lever Adjusting Link
116	17597		Shift Lever Spring Brkt.
117	710-0289		Brake Rod Guide Brkt.
118	710-0599		Hex Bolt 1/4-20 x .50 Lg.
119	714-0149B		Hex Washer Hd. Tap Scr. 1/4-20 x .5" Lg.
120	725-1657A		Internal Cotter Pin
121	720-0232		Safety Switch (Clutch) New Part
122	726-0231		Knob
123	732-0525		Retaining Ring
124	710-0650		Compression Spring 1.5" Lg.
125	736-0226		Hex Washer Hd. Scr. 5/16-18 x 7/8" Lg.
			Flat Washer .469" I.D. x .88"

Ref #	Part Number	Qty	Description
126	747-0694A		Shift Rod Ass'y.
127	747-0685		Shift Rod
130	17179		Shift Lever Support
131	710-0227		Hex Washer Hd. #8 x .50" Lg.
132	726-0222		Insulator Nut Plate
133	725-0758		Spring Switch
134	710-0502A		Hex Tap Scr. 3/8-16 x 1.25"
135	710-0672		Hex Bolt 5/16-24 x 1 1/4" Lg. Gr. 5
137	712-0123		Hex Nut 5/16-24Thd.
138			Engine
141	736-0141		Wave Washer .445" I.D.
143	741-0404	2 Req'd	Needle Brg.
144	777-9586A	13AH451F352 (899) 16 of 24	7-Speed Indicator Strip (470 Series)
	777-0404A	Drive/Frame Assembly/Pedal	5-Speed Indicator Strip (450 Series)
	747-0816		Hook For Speed Indicator
145	732-0691		Ext. Spring 2.04" Lg. (Style 0, 1)



Ref #	Part Number	Qty	Description
1	629-0702		Ground Wire New Part
2	725-1705C		Dry Battery New Part
	725-1704		Wet Battery
	725-1723		Acid Pack (Not shown in figure)
3	629-0747		Electric Wire - 8.0" Lg.
4	725-1426		Solenoid
5	725-0459		Circuit Breaker
6	732-1644		Spring Switch (Reverse)
7	725-1657A		Safety Switch
8	725-0267		Ignition Switch
9	725-0634		Light Switch (Optional)
11	629-0195		Harness
12	725-1649	13AH451F352 (P207) 18 of 24	Socket New Part; (Sq. Headlights)
13	725-0963	Electrical/Switches	Bulb (Sq. Headlights)
14	725-0916A		Ground Wire
15	629-0086		Headlight Harness w/Amp & Light Switch
	629-0103		Headlight Harness
17	725-1303		Safety Switch (Seat)
18	725-1439		Safety Switch (Seat)
19	725-0925		Ammeter (Optional)




Ref #	Part Number	Qty	Description
2	712-0211		U-Nut 5/16-18 Thd.
3	710-0118		Hex Bolt 5/16-18 x .75" Lg.
4	725-0963		Bulb
5	710-0258		Hex Bolt 1/4-20 x .62" Lg.
6	725-1651		Socket
7	731-1099A		Lens
8	714-0104		Int. Cotter Pin 5/16" Dia.
9	726-0130		Speed Nut
10	710-0351		Truss Mach. B-Tap Scr. #10 x .5"
11	712-3027		Lock Nut 1/4-20 Thd.
12	723-0302		Hood Stop
13	732-0699		Hood Spring
14	712-0272	13AH451F352 (P097) 20 of 24	Hex Tap Scr. #10-24 Thd.
15	736-0413	Hood and Grille Assembly	Spring Washer .39" I.D. x .62" O.D.
16	738-0952		Shld. Bolt
17	749-0722B		Grille Support
19	712-3006		Hex Nut 1/4-20 Thd. (Gr. 5)
20	736-0329		Lock Washer 1/4" I.D.
21	710-0589		Hex Tap Scr. #10-16 x .75" Lg.
22	736-0400		FI-Washer .218" I.D. x .62"
23	17940B		Grille
24	17941		Hood
25	710-0473		Truss Mach. Scr. #10-24 x .5"

No
Diagram
Available

Parts List
Only

Ref #	Part Number	Qty	Description
	751-0302		Muffler (10, 11, 11.5 & 12 H.P. Briggs & Stratton)
	712-0250		Conduit Lock Nut
	751-0640		Muffler (12 H.P. Tecumseh)
	738-0636		Shoulder Bolt
	721-0208		Gasket

13AH451F352 (Page) 22 of 24
Muffler Information



Ref #	Part Number	Qty	Description
	918-0166B	1	Transaxle Complete
1	732-0614		Wire Ring
2	716-0231		Retaining Ring
4	710-1325		Scritt 1/4-20 x 1.625
5	719-0358		Upper Housing New Part
8	711-0861		Input Shaft
10	736-0335		Thrust Washer 5/8" I.D. x 1.25" Lg.
11	717-0633		Pinion Input 14T
12	716-0108		Retaining Ring
13	711-1016		Drive Shaft L.H. Brake
14	741-0336		Flange Brg. 5/8" I.D. x 3/4" Lg.
15	717-1362		Bevel Gear 42T Small I.D.
16	717-1363		Bevel Gear 42T Large I.D.
17	718-0228		Clutch Collar
23	741-0340		Sleeve Bearing 3/4" I.D. x 1.0"
24	721-0338		Oil Seal 3/4" I.D.
26	736-0445		Flat Washer .760" I.D. x 1.5" O.D.
29			Part of Ref. 28
32	736-0495		Thrust Washer 5/8" x 1" x .025"
	736-0336		Flat Washer 5/8" x 1" x .030"
	736-0494		Thrust Washer 5/8" x 1" x .035"
	736-0337		Flat Washer 5/8" x 1" x .040"
34	719-0313B		Lower Housing
35	718-0150		Anti-Rotation Brkt.
38	712-0273		Hex Nut 5/16-24 Thd.
39	736-0371		Flat Washer .344" I.D. x .875" O.D.
40	717-0772A		Actuating Arm
41	761-0198		Brake Yoke
42	717-0682		Puck Plate
43	717-0678		Brake Puck
45	761-0202		Brake Disc
46	741-0337		Flange Bearing 5/8" I.D. x 15/16"
48	611-0011		Shift Fork Ass'y.
49	741-0862		Ball Detent .250" Dia.
50	732-0863		Spring Detent
52	741-0335		Needle Brg. 5/8" I.D. x 1/2" Lg.
54	736-0349		Flat Washer 5/8" I.D. x 1" O.D.
55	741-0343		Actuating Pin 5/16" Dia.
56	710-1206		Hex Wash Hd. Self-Tap Scr.
57	717-1364		Differential Gear 58T
58	736-0349		Flat Washer 5/8" I.D. x 1" O.D.
59	736-0495		Thrust Washer 5/8" I.D. x 1"
60	736-0492		Flat Washer .76" x 1.5" x .010"
	736-0493		Flat Washer .76" x 1.5" x .020"
	736-0351		Flat Washer .76" x 1.5" x .030"
	736-0445		Flat Washer .76" x 1.5" x .040"
61	736-0519		Thrust Washer
62	618-0233		Differential Ass'y.
63	732-0743		L.H. Brake Spring New Part
	737-0289		Grease Shell (15 oz.)

13AH451F352 (2008) 24 of 24
Transaxle