


PARTS LIST




PARTS LIST

Craftsman 5.5 HP Snow Thrower Model 247.88355

1.	731-2635	Snow Removal Tool Mount	29.	684-04107	Spiral Assembly, LH
2.	684-04057	Impeller Assembly, 12" Dia.	30.	684-04108	Spiral Assembly, RH
3.	710-0347	Hex Screw, 3/8-16, 1.75, Gr5	31.	731-04870	Spacer, 1.25 OD x .75 ID x 1.00
4.	710-0451	Bolt, Carriage, 5/16-18, .750 Gr1	32.	736-0188	Washer, Flat, .76 x 1.49 x .06
5.	710-0604A	Screw, 5/16-18, 0.625	33.	741-0493A	Bushing, Flange, .80 ID x .91 OD
6.	710-0703	Screw, Carriage, 1/4-20, .750, Gr5	34.	790-00087A	Housing, 1" Hex Bearing
7.	712-04063	Nut, Flange Lock, 5/16-18, Nylon	35.	790-00120	Shave Plate, 2.25 x 23.66
8.	712-04064	Nut, Flange Lock, 1/4-20, Nylon	36.	784-5580	Slide Shoe
9.	712-04065	Nut, Flange Lock, 3/8-16, Nylon	37.	719-0319	Housing, Auger, RH Reduced
10.	714-04040	Cotter Pin, Bow-tie	38.	719-0320	Housing, Auger, LH Reduced
11.	725-0157	Cable, Tie, 3/16 x .05 x 7.4	39.	721-0179	Seal, Oil, .750 ID
12.	726-04012	Nut, Push-on, .25 Dia	40.	741-0662	Bearing, Flange, .75 x 1.0 x .59
13.	731-04705	Chute, Adapter 5" Dia	41.	710-0642	Screw, Self-tapping, 1/4-20, 0.750
14.	732-0611	Spring, Extension, .38 OD x 3.6	42.	711-04285	Axle, Auger, 24"
15.	736-0174	Washer, Wave, .625 x .885 x .015	43.	714-0161	Key, Hi-pro 3/16 x 5/8
16.	736-0242	Washer, Bell, .340 x .872 x .060	44.	715-04021	Pin, Dowel, .25 OD x 1.2
17.	736-0463	Washer, Flat, .25 x .630 x .0515	45.	717-04126	Shaft, Worm .75 OD
18.	731-2643	Snow Removal Tool	46.	717-0528A	Gear, Worm 20T
19.	738-0143	Screw, Shoulder, .498 x .34, 3/8-16	47.	718-04071	Collar, Thrust
20.	738-0281	Screw, Shoulder, .625 x .17, 3/8-16	48.	721-0325	Plug, 1/4 x .437
21.	738-04124A	Shear Pin, .25 x 1.50	49.	721-0327	Seal, Oil, .75 x 1 x .131
22.	741-0245	Bearing, Hex Flange x .75 ID	50.	736-0351	Washer, Flat, .760 ID x 1.5 OD
23.	741-0309	Bearing, Ball, .75 ID x 1.85 OD	51.	736-3084	Washer, Flat, .51 x 1.12
24.	756-0981A	Flat Pulley, Idler, 2.75 OD	52.	741-0663	Bearing, Flange, .75 x 1.0 x .925
25.	790-00075	Housing, Bearing, 1.85 ID	53.	741-0661A	Bearing, Flange, .75 x 1.00 x .975
26.	790-00080	Bracket, Auger Idler w/ Brake	54.	746-04230	Clutch Cable, Auger, 47.23"
27.	618-04171	Gearbox Assembly, Auger, 24"	55.	629-0071	Extention Cord, 110V
28.	684-04069	Housing Assembly, Auger 24"			

PARTS LIST




PARTS LIST

Craftsman 5.5 HP Snow Thrower Model 247.88355

1.	631-04133	Handle Ass'y, Lock LH	22.	710-1260A	Screw, 5/16-18, 0.75, Gr5
2.	631-04134A	Handle Ass'y, Lock, RH	23.	714-0104	Pin, Cotter, .072 x 1.13
3.	684-04106B	Handle Ass'y, Engagement LH	24.	720-0201A	Crank Knob, 1.0 Dia. x 3.2, Black
4.	684-04105A	Handle Ass'y, Engagement, RH	25.	720-04072	Knob Assembly, Black, 5/16-18
5.	710-0376	Screw, Self-tapping, 5/16-18, .625	26.	726-0100	Cap, Push, 3/8 Rod
6.	710-0604A	Screw, Self-tapping, 5/16-18, 1.0	27.	735-0234	Grommet, .44 ID x .94 OD x .50
7.	710-0606	Screw, Self-tapping, 1/4-20, 1.50	28.	736-0185	Washer, Flat, .375 x .738 x .063
8.	710-1233	Screw, Machine, #10-24, 1.375	29.	736-0451	Washer, Saddle, 320 x .93 x .060
9.	712-04063	Nut, Flange Lock, 5/16-18, Nylon	30.	747-04263	Eye Bolt, Chute Crank
10.	712-04064	Nut, Flange Lock, 1/4-20, Nylon	31.	749-04138	Handle, Lower
11.	720-0223	Grip, 0.5 ID x 3.45	32.	749-04141	Handle, Upper, RH
12.	720-0274	Grip, 1.0 ID x 5.0	33.	749-04142	Handle, Upper, LH
13.	732-04205	Spring Lever, Shift	34.	731-04912A	Chute, Lower, 5.0 Diameter
14.	735-0199A	Bumper, Rubber, .62 OD x .22	35.	710-0276	Bolt, Carriage, 5/16-18, 1.0
15.	736-3015	Washer, Flat, .469 x .875 x .105	36.	710-04071	Bolt, Carriage, 5/16-18, 1.0
16.	738-04122	Screw, Shoulder, 1/4-20, .437	37.	710-0451	Bolt, Carriage, 5/16-18, .750
17.	747-04243	Lever, Shift	38.	731-04426A	Chute, Upper, w/ Label
18.	790-00100	Panel, Handle	39.	731-04869	Chute, Flange Keeper
19.	790-00187A	Panel, Speed Select (5 FW, 2 RV)	40.	741-0475	Bushing, Plastic, .380
20.	684-04104	Crank Assembly, Chute	41.	784-5647	Bracket, Chute Crank
21.	710-0449	Screw, Carriage, 5/16-18, 2.25			

PARTS LIST




PARTS LIST

Craftsman 5.5 HP Snow Thrower Model 247.88355

1.	656-04025A	Disc Assembly, Friction Wheel	33.	790-00206A	Guide Bracket, Auger Cable
2.	684-04153	Friction Wheel Assembly, 5.5 OD	34.	790-00207A	Guide Bracket, Drive Cable
3.	684-04154	Support Bracket, Friction Wheel	35.	790-00226	Cover, Frame
4.	684-04156	Shift Assembly, Rod	36.	634-04167A	LH Wheel Assembly, 13 x 4 x 6
5.	710-0627	Hex Screw, 5/16-24, .750, Gr5		634-04168A	RH Wheel Assembly, 13 x 4 x 6
6.	710-0788	Screw, 1/4-20, 1.000	37.	731-04873	Spacer, 1.25 x .75 x 3.0
7.	710-0896	Screw, 1/4-14 x .625	38.	738-04168	Axle, .75 x 22"
8.	712-04065	Nut, Flange Lock, 3/8-16, Nylon	39.	741-0919	Ball Bearing
9.	712-0413	Nut, Jam Lock, 5/8-18, Gr5, Nylon	40.	710-0106	Hex Screw, 1/4-20, 1.25, Gr5
10.	714-0126	Key, Hi Pro, 3/16 x 3/4 Dia.	41.	710-0191	Hex Screw, 3/8-24, 1.25, Gr8
11.	716-0104	E-ring, .500 Dia.	42.	710-04520	Hex Screw, 5/16-24, 1.25, Gr5
12.	716-0136	E-ring, Retaining, .875 Dia.	43.	710-0654A	Screw, Sems, 3/8-16, 1.00
13.	716-0231	E-ring, .750 Dia.	44.	710-1245B	Hex Screw, 5/16-24, .875, Gr8
14.	717-04209	Hex Shaft, .8125, 7-Tooth	45.	712-04064	Nut, Flange Lock, 1/4-20, Nylon
15.	717-04230	Gear, 80-Tooth	46.	726-04012	Nut, Push-on, .25 Dia.
16.	726-0221	Speed Nut, .500	47.	731-04792A	Cover, Belt
17.	732-0264	Extension Spring	48.	732-04308	Spring, Torsion, .850 ID x .354
18.	736-0242	Washer, Bell, .340 x .872 x .060	49.	736-0247	Washer, Flat, .406 x 1.25 x .157
19.	736-0287	Washer, Flat, .793 x 1.24 x .060	50.	736-0119	Washer, Lock .3125
20.	736-04161	Washer, Flat, .75 x 1.00 x .060	51.	736-0505	Washer, Flat, .34 x 1.50 x .150
21.	738-04164A	Pin, Friction Disc	52.	748-04053	Pulley, Adapter, .75 Dia.
22.	741-04098	Ball Bearing, 30 x 55 x 13	53.	748-04112	Spacer, Shoulder, .317 x .50 x .102
23.	738-04184A	Screw, Shoulder, .37 x .105, 1/4-20	54.	750-04303	Spacer, .875 ID x 1.185 OD
24.	738-0924A	Screw, 1/4-28, .375	55.	750-04477	Spacer, .340 x .750 x .360
25.	741-0245	Bearing, Hex Flange x .75 ID	56.	754-04050	Belt, Auger Drive
26.	741-0563	Bearing, Ball, 17 x 40 x 12	57.	754-04088	Belt, Wheel Drive
27.	746-04229	Clutch Cable, Wheel, 44.95"	58.	756-04109	Pulley, Auger Drive, 8.1 x .5
28.	735-04054	Rubber, Friction Wheel, 5.5 OD	59.	756-04113	Pulley, Half, V x 2.600 OD
29.	748-0190	Spacer, .508 ID x .75 OD x .68	60.	756-04179	Pulley, Half, 1/4-V x 1.5 OD
30.	756-0625	Roller, Cable	61.	790-00208	Idler Bracket, Wheel Drive
31.	790-00096	Front Guide Bracket, Auger Cable	62.	790-00230	Sleeve, Bearing Idler
32.	790-00180	Frame	63.	750-04571	Spacer, Shoulder, .26 x .79 x .538

PARTS LIST



PARTS LIST

Tecumseh 5.5 HP Engine Model LH195SP-67514

1	36469A	Cylinder (Incl. 2,20,72 & 125)	1
2	26727	Dowel Pin	2
5	30969	Extension Cap (1/4-18 NPT)	1
14	28277	Washer	1
15	31334	Governor Rod	1
16	37729	Governor Lever	1
17	31335	Governor Lever Clamp	1
18	651018	Screw, T-15, 8-32 x 19/64"	1
19	31426	Throttle Spring	1
20	32600	Oil Seal	1
25	36552	Blower Housing Baffle (Incl. 2)	1
25A	35883	Baffle Extension	1
26	650802	Screw, 1/4-20 x 5/8"	2
26A	650926	Screw, 8-32 x 21/64"	1
30	37842	Crankshaft	1
40	36073	Piston, Pin & Ring Set (Std.)	1
40	36074	Piston, Pin & Ring Set (.010")	1
40	36075	Piston, Pin & Ring Set (.020")	1
41	36070	Piston & Pin Ass'y. (Std.) (In)	1
41	36071	Piston & Pin Ass'y. (.010" OS) Incl. 43	1
41	36072	Piston & Pin Ass'y. (.020" OS) Incl. 43	1
42	36076	Ring Set (Std.)	1
42	36077	Ring Set (.010" OS)	1
42	36078	Ring Set (.020" OS)	1
43	20381	Piston Pin Retaining Ring	2
45	32875A	Connecting Rod Ass'y. (Incl. 4)	1
46	32610A	Connecting Rod Bolt	2
48	37670	Valve Lifter	2
49	32654	Oil Dipper	1
50	37671	Camshaft (MCR)	1
60	29745	Blower Housing Extension	1
64	30063	Screw, T-30, 1/4-20 x 1/2"	1
64A	8345	Washer	1
65	650128	Screw, 10-24 x 1/2" (1/4-18 NPT x 4-3/4)	1
69	27677A	* Cylinder Cover Gasket	1
70	34674C	Cylinder Cover (Incl. 75 thru	2
72	27642	Oil Plug	2
75	27897	Oil Seal	1
80	30574A	Governor Shaft	1
81	30590A	Washer	1
82	30591	Governor Gear Assembly (Incl.	1
83	30588A	Governor Spool	1
86	650488	Screw, 1/4-20 x 1-1/4"	7
89	610961	Flywheel Key	1
90	611195	Flywheel	1
92	650815	Belleville Washer	1
93	650816	Flywheel Nut	1
100	34443C	Solid State Ignition	1
101	610118	Spark Plug Cover	1
102	651024	Solid State Mounting Stud	2
103	651007	Screw, T-15, 10-24 x 15/16"	2
110	35182	Ground Wire	1
110A	36874	Ground Wire	1
119	36443	* Cylinder Head Gasket	1
120	37675	Cylinder Head (Incl. 131)	1
125	36471	Exhaust Valve (Std.) (Incl. 15)	1
125	36472	Exhaust Valve (1/32" OS) (Incl.)	1
126	32644A	Intake Valve (Std.) (Incl. 151)	1
127	650691	Washer	1
130	6021A	Screw, 5/16-18 x 1-1/2"	2
130A	650694A	Screw, 5/16-18 x 2"	5
130B	650818	Screw, 5/16-18 x 1-1/2"	1
135	35395	Resistor Spark Plug (RJ19LM)	1
150	31672	Valve Spring	2
151	31673	Valve Spring Cap	2
169	27234A	* Valve Cover Gasket [2]	2
170	27666	Breather Body	1
171	31410	Breather Element	1
172	34146	Valve Cover	1
173	35350	Breather Tube	1
174	650783	Screw, 10-24 x 3/4"	2
178	29752	Nut & Lock Washer, 1/4-28"	2
181	650870	Screw, 1/4-28 x 1-11/16"	1
182	6201	Screw, 1/4-28 x 7/8"	1
183	34583A	Choke bracket	1
184	26756	* Carburetor To Intake Pipe Ga	1
185	33691	Intake Pipe	1
186	32698	Governor Link	1
200	36677	Control Bracket (Incl. 203 thr	1
203	31342	Compression Spring	1
204	651029	Screw, T-10, 5-40 x 7/16"	1
206	610973	Terminal	1
215	35440	Control Knob	1
219	34582	Choke Rod	1
220	35438	Choke Knob	1
222	28820	Screw, 10-32 x 1/2"	2

PARTS LIST

223	650664	Screw, 1/4-20 x 1-19/32"	2
224	33673A	*Intake Pipe Gasket	1
253	36701	Compression Release Weight	1
254	36702	Compression Release Spring	1
260	35656A	Blower Housing	1
262	650737	Screw, 1/4-20 x 1/2"	2
267	34212	Hold Down Bracket	1
268	30200	Screw, 10-24 x 9/16"	1
274	33670A	*Exhaust Gasket	1
275	35771A	Muffler (Incl. 274)	1
277	792005	Screw, 1/4-20 x 2-1/2"	2
285	36467A	Starter Cup	1
287	650926	Screw, 8-32 x 21/64"	2
290	30705	Fuel Line	1
292	26460	Fuel Line Clamp	2
298	650665	Screw, 1/4-15 x 3/4"	2
300	35584	Fuel Tank (Incl. 292 & 301)	1
301	37845	Fuel Cap	1
310	35556	Dipstick	1
311	37246	Oil Fill Plug	1
312	27625	Oil Fill Plug Gasket	1
313	34080	Spacer	1
328	35062	Ignition Key	2
329	610973	Terminal	1
329A	651060	Screw, 8-32 x 23/64"	1


335	35072	Carburetor Cover	1
338	650257	Screw, 8-32 x 5/16"	2
340	36247	Fuel Tank Bracket	1
342	30063	Screw, T-30, 1/4-20 x 1/2"	1
342A	650675	Washer	2
345	33344	Heat Baffle	1
350	570682A	Primer Assembly	1
351	32180C	Primer Line	1
355	590574	Starter Handle (Mitten Grip)	1
364	33333	Carburetor Cover Bracket	1
364A	37673	Locking Plate	1
365	650735	Screw, 10-24 x 3/8"	1
370A	36261	Instruction Decal	1
370B	35282	Speed Control Decal	1
370C	36501	Primer Decal	1
370D	36534	Caution Decal	1
370I	37119	Warning Decal	1
370K	36695	Starter Decal	1
380	640084B	Carburetor (Incl. 184)	1
390	590742	Rewind Starter †	1
396	33290E	Electric Starter Motor 110 Volt	0
396	730266	Electric Starter Kit (Optional) ††	0
400	36444	* Gasket Set	1
600	651013	Washer	1
900	754336	Replacement Short Block, order 71-999	1

† This engine may have been built with the 590707 starter.

†† (120V) Starter Kit, 18-watt flywheel w/ring gear, 18-watt alternator, and mounting hardware.


* Included in this Gasket Set.

0	590742	Rewind Starter	1
3	590740	Retainer	1
6	590616	Starter Dog	2
7	590617	Dog Spring	2
8	590645A	Pulley & Rewind Spring Ass'y	1
11	590647A	Starter Housing Ass'y	1
12	590535	Starter Rope (Length 98" x 9/64" dia.)	1
13	590574	Mitten Grip Handle (Not included w/starter)	1
14	590760	Spring Clip	1



PARTS LIST

Tecumseh 5.5 HP Engine Model LH195SP-67514



0	640084B	Carburetor (Incl. 184 of Engine Parts List)	1
1	631615	Throttle Shaft & Lever Assembly	1
2	631767	Throttle Return Spring	1
6	640070	Throttle Shutter	1
7	650506	Shutter Screw †	2
10	632108	Choke Shaft & Lever Assembly	1
14	631890	Choke Shutter	1
15	630735	Choke Positioning Spring	1
16	631807	Fuel Fitting	1
17	651025	Throttle Crack Screw/Idle Speed Screw	1
18	630766	Tension Spring	1
20	640027	Idle Restrictor Screw	1
20A	640053	Idle Restrictor Screw Cap	1
25	631951	Float Bowl Assembly (Incl. 32 & 33)	1
27	631024	Float Shaft †	1
28	632802	Float (Plastic)	1
29	631028	Float Bowl O-Ring †	1
30	631021A	Inlet Needle, Seat & Clip (Incl. 31) †	1
31	631022	Spring Clip	1
32	27136A	Bowl Drain Assembly	1
33	27554	Drain Plunger Gasket †	1
36	632745	Main Nozzle Tube	1
37	632547	O-Ring, Main Nozzle Tube †	2
40	640131	High Speed Bowl Nut	1
44	27110A	Bowl Nut Washer †	1
47	630748	Welch Plug, Idle Mixture Well †	1
48	631027	Welch Plug, Atmospheric Vent †	1
60	632760B	Repair kit (Incl. Items Marked † in Notes)	1

0	590707	Recoil Starter	0
1	590599A	Spring Pin (Incl. 4)	1
2	590600	Washer	1
3	590696	Retainer	1
4	590601	Washer	1
5	590697	Brake Spring	1
6	590698	Starter Dog	2
7	590699	Dog Spring	2
8	590709	Pulley & Rewind Spring Ass'y.	1
11	590708	Starter Housing Ass'y.	1
12	590535	Starter Rope (98" X 9/64" dia.)	1
13	590574	Mitten Grip Handle (Not included with starter)	1

