


**ENGINE PARTS - MODELS TB475SS  
4-CYCLE GAS TRIMMER  
PPN 41BDT47C063**




# ENGINE PARTS - MODELS TB475SS

## 4-CYCLE GAS TRIMMER

PPN 41BDT47C063

<u>Item</u>	<u>Part No.</u>	<u>Description</u>	<u>Item</u>	<u>Part No.</u>	<u>Description</u>
1	753-04083	Engine Cover	46	791-181247	Palnut
2	791-182339	Engine Cover Screws	47	753-1199	Recoil Pulley
3	791-181025	Valve Cover Screw	48	753-04286	Recoil Spring
4	791-182098	Valve Cover	49	791-182366	Nut Clip
5	791-182099	Valve Cover Gasket	50	791-181079	Pull Handle
6	791-182340	Rocker Adjustment Nut	51	791-611061	Rope Guide
7	791-182101	Rocker Arm Pivot	52	791-613103	Rope
8	791-182100	Rocker Arm	53	791-181020	Starter Housing Screw
9	791-182341	Rocker Arm Stud	54	753-1237	Starter Housing Assembly (includes 46-52)
10	791-182103	Valve Spring Retainer	55	791-182368	Clutch Washer
11	791-181038	Valve Spring	56	753-1238	Clutch with Spacer
12	791-182102	Push Rod Guide	57	791-153592	Clutch Drum
13	791-181033	Push Rod	58	753-1239	Clutch Cover
14	791-182745	Cylinder Head (includes 9 & 12)	59	791-145569	Anti-Rotation Screw
15	791-182344	Cylinder Screw	60	753-1240	Screw
16	791-182345	Intake Baffle	61	753-1241	Nut
17	791-182749	Carburetor Mount Gasket	62	791-181345	Clutch Cover Screws
18	791-181034	Nut	63	753-04298	Ignition Module with Screws
19	791-182347	Carburetor Mount (includes 18)	64	791-181065	Spacer
20	791-182348	Carburetor Mount Screw	65	753-04299	Flywheel
21	791-182732	Carburetor Gasket	66	791-182743	Shroud Assembly w/Screws
22	753-04296	Carburetor with Primer	67	791-182376	Crankcase Assembly (includes 68 & 69)
23	791-181751	O-Ring, Carburetor	68	791-182375	90° Elbow
24	753-04305	Air Filter/Choke Cover Assembly (includes 27)	69	791-182379	Breather Hose
25	791-182097	Breather Tube	70	791-181015	Cam Gear
26	791-181750	Air Filter Mounting Screw	71	753-1242	Cam Follower Set
27	791-181757	Air Filter	72	791-181013	Cam Bracket
28	753-04316	Air Filter Cover	73	791-181012	Cam Bracket Screw
29	753-1229	Fuel Cap	74	791-181040	Valves, Intake and Exhaust
30	791-182352	Fuel Return Line	75	791-182374	Cylinder Gasket
31	791-182353	Fuel Pick-Up Line with Filter	76	791-181018	Oil Pan Gasket
32	791-181080	Screw	77	791-182377	Oil Pan (includes 76 & 78)
33	791-182354	Washer	78	791-181020	Oil Pan Screws
34	753-1230	Fuel Tank Assembly (includes 29-31)	79	753-04041	Dipstick Assembly
35	791-182356	Fuel Tank Shield	80	791-182290	O-Ring
36	753-04297	Throttle Cable	81	791-181009	Connecting Rod
37	791-182358	Muffler Baffle	82	791-181008	Wrist Pin Button
38	791-181048	Muffler Gasket	83	753-1243	Piston
39	791-182359	Muffler (includes 38, 40-42)	84	791-181006	Wrist Pin
40	791-180890	Spark Arrestor Screen	85	791-182295	Piston Ring Set
41	791-181045	Screen Cover	86	791-182409	Washer
42	791-181046	Screw	87	791-181861	Screw
43	791-182361	Muffler Mounting Screw	88	791-612468	Compression Spring
44	753-04092	Muffler Cover	89	791-182537	Grommet
45	791-182804	Switch Wire Assembly	*	791-180852B	Spark Plug
			*	753-1245	Short Block Assembly (includes 3-15, 66-85)
			*	791-180142	Starter Pawl Repair Kit
			*	791-182156	Carburetor Repair Kit
			*	753-1248	Gasket Diaphragm Repair Kit
			*		Parts not shown

**BOOM AND TRIMMER PARTS - MODEL TB475SS**  
**4-CYCLE GAS TRIMMER**  
**PPN 41BDT47C063**



Item	Part No.	Description
1	753-04234	Throttle Housing & Trigger Assembly (includes 2 & 3)
2	753-04119	Throttle Trigger
3	791-182690	Throttle Trigger Spring
4	791-182405	Switch Assembly
5	791-180869	Deluxe D-Handle Assembly ( includes 6-8)
6	791-182870	Handle Mount Hardware
7	791-182167	Deluxe D-Handle
8	791-182168	Bottom Clamp
9	753-1247	Upper Drive Shaft Housing Assembly
10	753-1190	EZ-Link™ Coupler (includes 11-14)
11	791-182057	Screw
12	791-181617	Bolt
13	791-181981	Adjustment Knob
14	791-181886	Knob Retaining Nut
15	791-182388	Lower Drive Shaft Housing Assembly
16	791-181166	Lower Flexible Drive Shaft
17	791-153597	Lower Clamp Assembly (includes 18)
18	791-145569	Anti-Rotation Screw
19	791-180547	Shield Mounting Hardware
20	753-1213	Shield and Blade Assembly (includes 21)
21	791-181823	Blade Assembly
22	791-181566	Gearbox Assembly
23	791-181457	Outer Spool & Eyelet Assembly
24	791-181458	Retaining Ring
25	791-181561	Thrust Washer
26	791-181459	Small Spring
27	753-04257	Slider
28	791-181532	E-Clip
29	791-181531	Spring
30	791-181462	Plunger
31	791-181463	C-Clip
32	791-181464	Inner Reel
33	791-181465	Large Spring
34	791-181467	Foam Seal
35	791-181468	Bump Head Knob Assembly (includes 33 & 34)

**Optional Accessories**

- \* 791-180120 Replacement Line, 0.095 Diameter
- \* 753-04218 Reel and Line Assembly
- \* 791-682075 Shoulder Strap Assembly

\* Items Not Shown