


Gasket Kit
 (★ Indicates Contents)

40.


Ref #	Part Number	Qty	Description
1	503108701		Screw
2	505316702		Cover
3	505316715		Diaphragm Included in Gasket/Diaphragm Kit.
4	505316734		Metering Lever Included in Gasket/Diaphragm Kit.
5	505316717		Screw
6	505316731		Pin
7	503117001		Needle Included in Gasket/Diaphragm Kit.
8	505316723		Spring Included in Gasket/Diaphragm Kit.
9	503483101		Ring
10	502119801		Clip
11	506028301		Washer
12	503483801		Lever
13	503483401	PP415 Gas Saw Page 2 of 10	Spring Return
14	502103101	CARBURETOR WP-28P BRI	Bushing
15	503117701		Spring
16	503117101		Ball
17	501666101		Filter Included in Gasket/Diaphragm Kit.
18	501468401		Spring
19	503404101		Washer
20	503404301		Screw
21	503482501		Cover-Pump
22	503117501		Screw
23	504210050		Spring
24	505316721		Spring
25	503483701		Needle-Low
26	503483601		Needle-High
27	503483301		Idle Screw
28	530035015		Screw
29	503482701		Valve
30	503482601		Shaft Ass'y.
31	503483501		Spring
32	503484001		Lever
33	505316707		Valve
34	503117201		Gasket-Pump Included in Gasket/Diaphragm Kit.
35	503192201		Screw
36	503482901		Lever
37	503482801		Choke Shaft
38	501467501		Gasket Included in Gasket/Diaphragm Kit.
39	503117301		Diaphragm-Pump Included in Gasket/Diaphragm Kit.
40	503088401		Gasket Kit



Ref #	Part Number	Qty	Description
1	503427001		Switch Ass'y.
2	501271302		Grommet
3	725528955		Screw
4	501485402		Plug Boot
5	501527407		Sleeve
6	503202520		Screw
7	501673501		Starter Dog Spring
8	503230042		Washer
9	501673201		Starter Dog
10	501819901		Screw
11	503212810		Screw
12	503511503		Flywheel Ass'y.
13	503281209	PP415 Gas Saw Page 4 of 10	Carburetor
14	503220001	EXTERNAL POWER UNIT	Nut
15	503210716		Screw
16	734180951		Washer
17	503423001		Air Baffle
18	503432101		Starter Pulley
19	503431901		Starter Spring
20	503142902		Washer
21	504654203		Handle
22	501201502		Rope
23	501630601		Eyelet
24	503200216		Screw
25	503434101		Pre Cleaner
26	503432503		Fan Housing/Starter Ass'y (Inc.11,15-23,30)
27	503200210		Screw
28	501814701		Shock Mount
29	530620203		Model 415
29	503620502		Model 475
30	503164001		Check Valve
31	501269702		Standard
31	504125014		Heavy Duty
32	503431401		Inner Sealing Ring
33	503438203		Tank & Handle Ass'y. (Incl. 37,38,49-54)
34	501278201		O Ring
35	501431401		Fuel Cap
36	503427502		Insert
37	503226501		Nut
38	501527801		Grommet
39	503432402		Choke Knob
40	503430401		Gasket
41	503443201		Fuel Filter
42	501768313		Fuel Line
43	503434001		Gasket
44	503431801		Outer Sealing Ring
45	503431501		Manifold Tube
46	503560003		Clamp
47	503436001		Grommet
48	503434801		Throttle Wire
49	503428001		Spring
50	503424901		Spring
51	503424402		Trigger Lock
52	720123820		Pin
53	503424502		Trigger
54	720123620		Pin

Ref #	Part Number	Qty	Description
55	503203242		Screw
56	503203216		Screw
57	503433103		Air Filter Cover
58	503433401		Std. Nylon Mesh
58	503433402		Flock Filter
58	503433403		Coarse Nylon Mesh
59	503202301		Screw
60	503432801		Air Inlet Tube
61	503424201		Cover
62	503431701		Sealing Ring
63	501768304		Fuel Line
64	501768307		Fuel Line
65	504357201		Brass Check Valve

PP415 Gas Saw Page 5 of 10
EXTERNAL POWER UNIT




Ref #	Part Number	Qty	Description
1	721430350		Pin
2	506093802		Actuator
3	503234502		Washer
4	503436101		Bushing
5	503200225		Screw
6	735311020		E-Clip
7	503200216		Screw
8	506093401		Brake Housing
9	720127050		Pin
10	503436701		Block
11	503436501		Spring
12	503436901		Actuator Arm
13	503435801	PP415 Gas Saw	Pin
14	503408101	HANDLEBAR	Spring
15	720123500		Pin
16	506094502		Band
17	503272101		E-Clip
18	503656502		Cup Washer
19	503432001		Clutch Bearing
20	501598002		Rim-3/8x7
20	505303661		Rim-3/8x8
21	503438401		Clutch Drum Ass'y. (Inclu. 17-20)
22	503524601		Clutch Ass'y.
23	503560401		Clutch Spring
24	725524355		Screw
25	501288501		Seal Ring
26	503426701		Oil Pickup Tube
27	501544102		Oil Pickup
28	503615801		Spring
29	503421301		Adjusting Screw
30	503422401		Spring
31	503421401		Pin
32	503230054		Washer
33	503421202		Pump Piston
34	503210632		Screw
35	503428201		Spring
36	503200230		Screw
37	503226501		Nut
38	503425802		Handlebar
39	503425102		Brace
40	503210619		Screw
41	503435702		Handlebar
42	504125014		Mount
43	503437401		Spacer
44	506132802		Spacer
45	503200265		Screw
46	503434201		Inner Spur
47	503200210		Screw
48	503624901		Dust Shield
49	503200212		Screw
50	503226501		Nut
51	503434301		Outer Spur
52	503438102		Wrap Around Handlebar Kit (Inc.7,36,41,42, 43,44,45,46,47,48,49,50,51)
54	503554201		Shim Washer (Only if originally equipped)

Ref #	Part Number	Qty	Description
55	503421501		Pump Drive Worm Gear
	502516701		Torx Wrench TX 20 Not Shown.
	502712701		Torx Wrench TX 25 Not Shown.
	502713101		Torx Wrench TX 30 Not Shown.
	503434401		Winter Kit Not Shown.
	506094404		Chain Brake Ass'y. Not Shown.
	503427201		Air Box Post Repair Kit Not Shown.

PP415 Gas SawPage 8 of 10
HANDLEBAR

⚠ WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.



Ref #	Part Number	Qty	Description
1	503433302		Cylinder Cover
2	503208601		Model 415
2	503439401		Model 475 Decal
3	503220001		Nut
4	506093101		Bar Clamp
5	501517201		Chain Pad
6	501814801		Bar Plate-Inner
7	503200216		Screw
8	503200265		Screw
9	503424101		Spur
10	505275719		Oil Seal
11	503230042		Washer
12	501686801	PP415 Gas Saw Page 10 of 10	Chain Catcher
13	501537101	INTERNAL POWER UNIT	Chain Adjuster
14	503200245		Screw
15	721613800		Vent Pin
16	501815701		Bar Stud
17	503422201		Oil Seal
18	503200225		Screw
19	501608201		Pop Rivet
20	506093301		Deflector
21	503203219		Screw
22	503206410		Screw
23	503435401		Exhaust Deflector
24	503435501		Spark Arrestor
25	503424301		Fitting
26	503200320		Screw
27	725538855		Screw
28	503713705		Muffler Ass'y (Incl. 22-24)
29	5030206420		Screw
30	503437901		Heat Shield
31	952030150		Spark Plug
32	503437504		Model 415
32	503420504		Model 475
33	503428601		Gasket
34	503289015		Model 415
34	503289019		Model 475
35	503437702		Model 415
35	503420802		Model 475
36	501511301		Piston Pin Bearing
37	737431200		Keeper
38	503433701		Shock Mount
39	503420005		Crankcase Ass'y. (Inc. 5,12,15,25,41,42)
40	503230035		Washer
41	501270801		Pin
42	738220225		Crankshaft Bearing
43	503554101		Rear Chain Catcher
44	506088602		Crankshaft Ass'y. (Inc. 36,42,45)
45	735880600		Flywheel Key
46	501626801		O Ring
47	501626601		Oil Cap Ass'y.
48	501444501		Bar Plate-Outer
49	503212806		Screw
50	503438301		Engine Gasket Kit