


TYPE 1




⚠ WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.

Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530057991	Assy - Throttle Cable	15.	530071772	Kit - Shield Assy (Incl. 11,12,14,16)
2.	530058000	Trigger	16.	530016152	Wingnut
3.	530057582	Throttle Hsg. (Right)	17.	952701666	Accy - TNG IV Cutting Head (Incl. 18 - 22)
4.	530015880	Screw - Throttle Hsg.	18.	530069690	Assy - Hub
5.	530015821	Bolt	19.	530401464	Spring - Compression
6.	530071773	Assy - Drive Shaft Hsg.	20.	530401466	Clip - Retainer - Head
7.	530095242	Shaft - Flex	21.	530401467	Screw
8.	530057581	Throttle Hsg. (Left)	22.	952711527	Accy - Spool w/Line
9.	530057587	Handle - Assist			Not Shown
10.	530016152	Wingnut			
11.	530052287	Line Limiter			
12.	530015966	Screw - Line Limiter			
13.	530095563	Dust Cup		530057720	Decal - Start Inst.
14.	530015820	Bolt		530055350	Decal - Shaft Warning


TYPE 2

⚠ WARNING
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.



Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530057991	Assy-Throttle Cable	15.	530071772	Kit-Shield Assy (Incl. 11,12,14,16)
2.	530058000	Trigger	16.	530016152	Wingnut
3.	530057582	Throttle Hsg. (Right)	17.	952701666	Accy-TNG IV Cutting Head (Incl. 18-22)
4.	530015880	Screw-Throttle Hsg.	18.	530069690	Assy-Hub
5.	530015821	Bolt	19.	530401464	Spring-Compression
6.	530071874	Assy-Drive Shaft Hsg.	20.	530401466	Clip-Retainer-Head
7.	530096275	Shaft-Flex	21.	530401467	Screw
8.	530057581	Throttle Hsg. (Left)	22.	952711527	Accy- Spool w/Line
9.	530058580	Assy-Handle (Incl. 5,10)			Not Shown
10.	530016152	Wingnut		545186837	Operator Manual
11.	545081862	Kit - Line Limiter (Incl. 12)		545144405	Decal-Shaft Warning
12.	530015966	Screw-Line Limiter			
13.	530095563	Dust Cup			
14.	530015820	Bolt			

TYPE 1,2



Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530015814	Screw	21.	530057584	Cover-Air Box	45.	530019264	Seal-C'case
2.	530058982	Bolt-Muffler	22.	530039223	Ignition Module	46.	530032125	Inner Bearing
3.	545227901	Assy-Muffler/Shield (Incl. 2)	23.	530038604	Coupling-Drive	47.	530069945	Assy-Connecting Rod
4.	530015953	Screw-Cylinder	24.	530016357	Screw	48.	530071750	O-Ring-C'case (kit)
5.	952030249	Spark Plug (RCJ 6Y)	25.	530014663	Assy-Leadwire	49.	530057954	Assy-Plug (incl.48)
6.	530012541	Cylinder	26.	530014662	Assy-Ground Wire	50.	530016386	Screw
7.	530071750	Seal-Cylinder (kit)	27.	530016392	Screw	51.	530057580	Shroud-Rear
8.	530055120	Piston Ring	28.	530058600	Assy.-Fan Hsg	52.	530016431	Retainer-Tank
9.	530015162	Retainer-Piston Pin	29.	530071356	Kit-Switch	53.	530058582	Assy-Fuel Tank (incl. filter, lines & fuel cap)
10.	530071357	Kit - Piston (Incl. 8, 9)	30.	530027569	Handle-Starter	54.	530014347	Assy-Fuel Cap
11.	530057829	Assy-Crankshaft	31.	530071767	Kit - Rope	55.	530069247	Kit-Fuel Line (Small)
12.	530012542	Assy-Crankcase (Incl. 44-46)	32.	530015810	Screw	56.	530069216	Kit-Fuel Line (Large)
13.	530071750	Seal-Cyl/Carb.(kit)	33.	530016124	Nut	57.	530095646	Assy-Fuel Pickup
14.	530057547	Adapter-Carb.	34.	530057588	Clip-Spring	58.	530071750	Kit-Engine Gasket (Incl. 7,13,16,48)
15.	530016309	Screw	35.	530016430	Screw			
16.	530071750	Gasket-Carb. (kit)	36.	530042085	Spring-Starter			
17.	530071752	Kit-Carb.(C1U-W18)	37.	530071786	Kit-Pulley-Starter			
(Note: Repair kits are not available for this carburetor)			38.	530027523	Retainer-Pulley			
18.	530057585	Air Box	39.	530015775	Screw			
19.	530016429	Screw	40.	530015828	Washer-Flat			
20.	530057781	Foam-Air Filter	41.	530054115	Assy-Flywheel			
			42.	530071768	Assy-C'case & C'shaft (Incl. 11,12,43)			
			43.	530015941	Retain. Ring-C'shaft			
			44.	530055728	Outer Bearing			