



**WA-215**



Ref #	Part Number	Qty	Description
1	530035014		Metering Diaphragm
2	530035001		Metering Diaphragm Gasket
3	530035211		Circuit Plate Gasket
4	530035212		Mixture Needle
5	530035214		Mixture Needle Spring
8	530035166		Fuel Pump Diaphragm
9	530035164		Fuel Pump Gasket
10	530035203		Idle Speed Screw
11	530035208		Idle Speed Spring
12	530035028		Metering Lever Pin
13	530035031		Metering Lever
14	530037330		Metering Lever Spring
15	530035016		Inlet Needle Valve
16	530035178		Fuel Inlet Screen
17	530035016		Metering Lever Pin Screw
18	530035264		Carb. Kwik Repair Kit (Inc. 1,2,3,8,9,12, 13,14,15,16,17)
19	530035219		Carb. Gasket/Diaphragm Kit (Inc. 1,2,3,8,9)

LT17 Gas Trimmer Page 2 of 9  
 CARBURETOR WA-215

**WA-218 #530-069647**



Carb.  
Repair  
Kit

1.

---


Ref #	Part Number	Qty	Description
1	530069668		Carburetor Repair Kit (DOT Indicates Contents)
2	530038404		Limiter Cap

---

LT17 Gas Trimmer Page 4 of 9  
CARBURETOR WA-218


**⚠ WARNING**

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.



Ref #	Part Number	Qty	Description
1	530094671		Drive Shaft
2	530010957		Handle
3	530036514		Throttle Hsg. (Left)
4	530036515		Throttle Hsg. (Right)
5	530036556		Throttle Lever
6	530015966		Screw-throttle Housing
7	530092062		Washer-Handle
8	530094742		Clamp-Handle
9	530015820		Bolt-Handle
10	530091373		Wing Nut-Handle
11	530015337		Screw-Line Limiter
12	530094570		Line Limiter
13	534235901		Locknut
14	530016107		Screw-Shield
15	530029373		Bracket Shield
16	530031111		Hex Wrench (5/32)
17	530069299		Shield Kit Ass'y. (Incl. 11-14)
18	530094874		Drive Shaft Hsg., LT7000
18	530095336		Drive Shaft Hsg., LT17
19	530094543		Dust Cup
20	952701618		Cutting Head Ass'y. (Incl. 21-25)
21	530094875		Hub Ass'y.
22	530094830		Spring
23	530094827		Release Button
24	952701619		Spool w/Line
25	530094828		Cover
26	530015197		Nut-Handle
27	530069252		"T" Handle Ass'y.
28	530094673		Handle
0	530047065		Carton Contents Bag, LT7000 Not Shown.
0	530047328		Carton Contents Bag, LT17 Not Shown.
0			Carton Contents Bag, Operator Manual Not Shown.
0	530081793		Carton Contents Bag, LT7000 Type 1 & 2 Not Shown.
0	530083152		Carton Contents Bag, LT7000 Type 3 Not Shown.
0	530082384		Carton Contents Bag, LT7000 French/English Type 3 Not Shown.
0	530083394		Carton Contents Bag, LT17 Not Shown.
0			Carton Contents Bag, Shaft Warning Decal Not Shown.
0	530029159		Carton Contents Bag, LT7000 English only Not Shown.
0	530029164		Carton Contents Bag, LT7000 French/English Not Shown.
0	530038907		Carton Contents Bag, LT17 Not Shown.
0			Carton Contents Bag, Instruction Decal Not Shown.
0	530038229		Carton Contents Bag, LT7000 French Not Shown.
0	530047436		Carton Contents Bag, LT7000,LT17 Tri/Lingual Not Shown.

LT17 Gas Trimmer Page 6 of 9  
 DRIVE SHAFT & CUTTING HEAD



Ref #	Part Number	Qty	Description
1	530029395		Starter Spring
2	530015775		Screw-Pulley
3	530027523		Retainer-Pulley
4	530015934		Screw-Shrd./Fan Hsg.
5	530027569		Starter Handle
6	530015810		Screw-Fan Hsg.
7	530019185		Gasket-Cylin./Carb.
8	530030075		Spark Plug
9	530019194		Gasket-Carb.
10	530015945		Retainer-C'Case
11	530014663		Lead Wire
12	530014662		Ground Wire
13	530039149		Flywheel Ass'y.
14	530039163		Ignition Module
15	530036145		Spacer-Ignition Mod.
16	530015954		Screw-Ignition Mod.
17	530015149		Washer-Flysheel
18	530027953		Drive Coupling
19	530014532		Crankshaft Ass'y. (Incl 10 & 23-25)
20	530069615		Connecting Rod Ass'y.
21	530036404		Piston Ring
22	530014861		Crankcase Ass'y.
23	530032125		Inner Bearing
24	530032124		Outer Bearing
25	530019179		C'case Seal
26	530015945		Retain. Ring-C'shaft
27	530069216		Fuel Line-Prim.Tnk.
28	530069247		Fuel LIne-Carb./Tnk.
29	530038602		Muffler Baffle-Exit
30	530015882		Screw-Flywheel
31	530029930		Muffler Spring
32	530014857		Shroud & Tank Assy., LT7000 Type 1
32	530047099		Shroud & Tank Assy., LT17 & LT7000 Type 2
33	530019181		Gasket-C'case
34	530069619		Cylinder
35	530069564		Carb. Adaptor Kit, LT17
35			Carb. Adaptor Kit, LT7000-See Ser. Ref. 1
36	530016014		Screw
37	530019223		Gasket-Cylinder
38	530035308		Carburetor, LT7000 Type 1 (WA-215)
38	530069647		Carburetor, LT17 & LT7000 Type 2 (WA-218 w/Limiter Cap)
39	530037308		Air Box, LT7000 Type 1
39	530037969		Air Box, LT17 & LT7000 Type 2
40	530037326		Choke Plate
41	530038102		Choke Shutter
42	530015254		Wave Washer
43	530015852		Choke Spacer
44	530015887		Screw-Carb.
45	530037413		Filter Plate
46	530037331		Air Filter Foam
47	530037292		Air Filter Cover
48	530015966		Screw-Filter Cover
49	530036744		Throttle Cable Ass'y.
50	530015814		Screw-Carb. Adaptor
51	530026119		Check Valve
52	530029717		Element

LT17 Gas Trim Page 8 of 9  
POWER UNIT Flywheel Ass'y.



Ref #	Part Number	Qty	Description
53	530029696		Retainer
54	530069571		Fuel Line-Prim./Carb.
55	530014347		Fuel Cap Ass'y.
56	530014362		Fuel Pickup Ass'y.
57	530069625		Engine Gasket Kit (Incl. 7,9,33,37)
58	530014729		C'case & C'shaft Assy. (Incl. 10,19,22-26)
59	530038114		On/Off Switch
60	530015953		Screw-Cylinder
61	530016072		Screw-Pinch Clamp
62	530015768		Locknut-Pinch Clamp
63	530014919		Fan Housing
64	530069232		Rope Kit
65	530016080		Screw-Rope Retain.
66	530069400		Starter Pulley Kit
67	530069380		Spark Arrestor Kit
68	530015162		Piston Pin Retainer
69	530069621		Piston Kit (Incl. 21,68 & Pin)
70	530069660		Muffler Kit
71	530029939		Starter Dog
72	530037730		Starter Spring
73	530038874		Primer Bulb Ass'y. LT17 & LT7000 Type 2
74	530016090		Screw-Primer LT17 & LT7000 Type 2

LT17 Gas Trimmer Page 9 of 9  
POWER UNIT