


Ref #	Part Number	Qty	Description
1	530035014		Metering Diaphragm
2	530035151		Metering Diaphragm Gasket
3	530035211		Circuit Plate Gasket
4	530035212		Mixture Needle
5	530035214		Mixture Needle Spring
6	530035217		Mixture Needle Washer
7	530035218		"O" Ring Mixture
8	530035166		Fuel Pump Diaphragm
9	530035164		Fuel Pump Gasket
10	530035203		Idle Speed Screw
11	530035208		Idle Speed Spring
12	530035028		Metering Lever Pin Included in Carburetor Kwik Repair Kit.
13	530035031		Metering Lever Included in Carburetor Kwik Repair Kit.
14	530035188		Metering Lever Spring Included in Carburetor Kwik Repair Kit.
15	530035106		Inlet Needle Valve Included in Carburetor Kwik Repair Kit.
16	530035178		Fuel Inlet Screen Included in Carburetor Kwik Repair Kit.
17	530035264		Carb. Kwik Repair Kit
18	530035219		Carb. Gasket/Diaphragm Kit

TT-20 Gas Turbine Page 2 of 7
TOP WA 11 BRE


▲ WARNING

All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by qualified service personnel.



Ref #	Part Number	Qty	Description
1	530027595		Grip
2	530015768		Nut
3	530094754		Model XT-20,TT-20
3	530094755		Model XT-50
4	530010957		Handle Assy.
5	530015197		Nut
6	530015774		Screw
7	530010959		Throttle Housing Assy.
8	530069252		"T" Handle Kit
9	530069282		Shield Kit Assy. (Inc.10,11,12,14)
10	530015337		Screw
11	530094570		Line Limiter
12	530015217		Locknut
13	530093653		Shield Bracket
14	530092243		Screw
15	530094543		Dust Cap
16	530094671		Model XT-20,TT-20
16	530094551		Model XT-50
17	530031111		Hex Wrench (5/32)
18	530030102		Shaft Lubrication
19	530702555		Model XT-20,TT-20
19	952702553		Model XT-50
20	530094562		Model XT-20,TT-20
20	530094620		Model TT-50
21	952702556		Model XT-20, TT-20, TT-50
22	530094521		Model XT-20,TT-20
22	530094494		Model TT-50
23	530094525		Spring Model XT-20,TT-20
24	530094523		Spool Post Model XT-20,TT-20
25	530015542		Screw Model XT-20,TT-20
26	530094522		Release Button Model XT-20,TT-20
A	530027871		Warning Decal

TT-20 Gas Trim Page 4 of 7
 CUTTING HEAD & DRIVE SHIELD BRACKET



Ref #	Part Number	Qty	Description
1	530015773		Screw
2	530027529		Air Filter Cover
3	530027530		Air Filter
4	530015766		Screw
5	530027528		Spacer
6	530015254		Wave Washer
7	530027526		Choke Shutter
8	530027527		Air Filter Plate
9	530021076		Fuel Line Kit
10	530010897		Fuel Pick-up Assy.
11	530035262		Model XT-20,TT-20 (WA-207)
11	530035259		Model XT-50 (WA-199)
12	530019156		Carburetor Gasket
13	530010807		Fuel Cap Assy.
14	530015775		Screw
15	530027955		Model XT-20,TT-20
15	530027549		Model XT-50
16	530027982		Model XT-20
16	530027982		Model XT-50
17	530019154		Crankcase/Shroud Gasket
18	530027593		Reed
19	530027594		Reed Stop
20	530014005		Model XT-20,TT-20
20	530010960		Model XT-50
21	530010945		Model XT-20,TT-20
21	530010934		Model XT-50
22	530015126		Flywheel Key
23	530015772		Screw
24	530015780		Screw
25	530027546		Kill Switch Insulator
26	530027547		Lead Wire
27	530015771		Screw
28	530014016		Crankcase Assy. (Inc.39 - 42)
29	530027545		Kill Switch Ramp
30	530027958		Kill Switch Button
31	530027959		Kill Switch Spring
32	530014004		Model XT-20,TT-20
32	530014015		Model XT-50
33	530015241		Screw
34	530015162		Piston Pin Retainer
35	530026413		Model XT-20,TT-20
35	530025875		Model XT-50
36	530019161		Cylinder Gasket
37	530069274		Model XT-20,TT-20
37	530069275		Model XT-50
38	530015788		Spacer
39	530032103		Inner Bearing
40	530015787		Retaining Ring
41	530019158		Crankshaft Seal
42	530032102		Outer Bearing
43	530015789		Crankshaft Retaining Ring
44	530015717		Screw
45	530027881		Muffler Guard
46	530069257		Muffler Kit
47	530024903		Muffler Attachment Spring
48	530012244		Model XT-20,TT-20

TT-20 Gas Trim Page 6 of 7
POWER UNIT
Carburetor Gasket

Ref #	Part Number	Qty	Description
48	530012235		Model XT-50
49	530030077		Spark Plug
50	530015239		Screw
51	530039134		Ignition Module Kit
52	530015776		Model XT-20,TT-20
52	530015128		Model XT-50
53	530039136		Flywheel Assy.
54	530027572		Flywheel Counterweight
55	530014045		Model XT-20,TT-20
55	530027948		Model XT-50
56	530027522		Starter Pulley
57	530027531		Starter Spring
58	530027569		Starter Handle
59	530069232		Rope Kit
60	530014009		Pulley Housing Assy. Model XT-50
61	530094189		Clutch Washer Model XT-50
62	530069254		Clutch Assy. Kit Model XT-50
63	530015796		Washer Model XT-50
64	530001733		Nut Model XT-50
65	530014017		Clutch Housing Model XT-50
66	530015767		Screw
67	530027511		Spacer Model XT-50
68	530015770		Screw
69	530015769		Screw
70	530015496		Screw
71	530027523		Retainer
72	530015768		Locknut
73	530069276		Engine Gasket Kit
74	952701612		Spark Arrestor Kit
75	530027953		Drive Coupling Model XT-20,TT-20
76	530015127		Washer Model XT-20,TT-20
77	530027525		Spacer Model XT-20,TT-20
78	530069247		Fuel Line Kit
79	530003933		Connector, Spark Plug
80	530003934		Boot, Spark Plug
81	530024435		Grommet - Plug Wire

TT-20 Gas Trimmer
POWER UNIT